

KRF-V4530D KRF-V5030D/V5030DE/V5030D-S KRF-V6030D/V6030DE/V6030D-S VR-405/406/414 SERVICE MANUAL



© 2000-1/B51-5597-00 (K/K) 3493

Note: On circuit description, please refer to KRF-V7030D service manual (B51-5598-00).







CONTENTS / ACCESSORIES /CAUTIONS

Contents

CONTENTS / ACCESSORIES / CAUTIONS.	2
CONTORLS	3
BLOCK DIAGRAM	5
CIRCUIT DESCRIPTION	6
ADJUSTMENT	8

PC BOARD	10
SCHEMATIC DIAGRAM	17
EXPLODED VIEW	33
PARTS LIST	34
SPECIFICATIONS	46

Accessories

FM indoor antenna (1) (T90-0836-05)



AM loop antenna (1) (T90-0852-05)



For VR-406 and KRF-V6030D Remote control unit (1) Batteries (R6/AA) (2) (A70-1330-05): RC-R0609

(A70-1331-05): RC-R0610(E type)



*AC plug adaptor (1) (E03-0115-05)



*Use to adapt the plug on the power cord to the shape of the wall outlet. (Accessory only for regions where use is necessary.)

For VR-405, VR-414, KRF-V5030D, and KRF-V4530D Remote control unit (1) Batteries (R6/AA) (2) (A70-1328-05): RC-R0509

(A70-1329-05): RC-R0510(E,T type)





Battery cover (A09-1178-08)

Cautions

Copy from instruction manual.

The manual covers the VR-407, VR-406, VR-405, VR-414, KRF-V7030D, KRF-V6030D, KRF-V5030D, and KRF-V4530D. Items such as functions, number of jacks, and remote control details differ somewhat between these models. To confirm the functions available on the model you have purchased, refer to the table below.

Model name	Remote		Terminal		
Woder Hame	Control	Speaker out	VIDEO 3 jacks	Front input	
VR-407 KRF-V7030D	RC-R0609	2 systems (A, B)	Equipped	Equipped	
VR-406 KRF-V6030D	RC-R0609	2 systems (A, B)	Not equipped	Not equipped	
VR-405/414 KRF-V5030D/ V4530D	RC-R0509	1 system	Not equipped	Not equipped	

This manual is divided into four sections, Preparations, Operations, Other, and Remote Control.

Remote Control (Separate booklet) (VR-407/VR-406/KRF-

V7030D/KRF-V6030D only)
Includes the "Quick Start Guide," which shows you how to operate other components using the remote control, as well as a detailed explanation of all remote control operations. Once you have registered your components with the proper setup codes, you'll be able to operate both this receiver and your other AV components (TV, VCR, DVD player, LD player, CD player, etc.) using the remote control supplied with this receiver.

VIDEO 2/MONITOR jacks (for VR-406/405/414/KRF-V6030D/V5030D/V4530D)

The receiver's VIDEO 2/MONITOR jacks can be used in two different ways. Make the appropriate setting for the component connected to the jack when the receiver is turned on.


Use as a VIDEO 2 jack

You can connect a video deck or the like to these jacks and perform video playback and recording. The initial factory setting is "VIDEO 2"

Use as a MONITOR jack

You can connect a cassette deck or the like to these jacks and make use of the deck's monitoring function during recording. Alternately, you can connect a graphic equalizer to these jacks to apply compensation to the music signal.

To use the VIDEO 2/MONITOR jacks as MONITOR jacks, hold down the MONITOR key of the main unit for more two seconds so that the indication shown below appears.



- At the same time the setting is switched to "MONITOR," the audio input source switches to tuner and the video input source switches
-) VIDEO 1.
 o switch the setting back to "VIDEO 2," once again hold down the MONITOR key for two seconds or more.

Memory back up function

Please note that the following items will be deleted from the unit's memory if the power cord is disconnected from the AC outlet for approximately 3 days.

- Power mode
- Input selector settings.
- Device preset.
 Picture output.
- Speaker ON/OFF
- Volume level.
- BASS, TREBLE, INPUT level.
- Subwoofer ON/OFF.
- Dimmer level Monitor ON/OFF
- MD/TAPE settings. 6CH/2CH input setting.
- · Listen mode setting.
- Speaker settings. Input mode setting.
- Midnight mode setting.
- Broadcast band.
- Frequency setting.
- · Tuning mode.

Resetting the Microcomputer

If the microcomputer may malfunction (unit cannot be operated, or shows an erroneous display) if the power cord is unplugged while the power is ON, or due to some other external factor. If this happens, execute the following procedure to reset the microcomputer and return the unit to its normal operating condition.

 Please note that resetting the microcomputer will clear the contents of the memory and returns the unit to the state it was in when it left

For U.S.A. and Canada


Unplug the power cord from the wall outlet, then plug it back in while holding down the POWER key.

For other countries

With the power cord plugged in, turn the POWER key OFF. Then, while holding down the ON/STANDBY key, press POWER.

Model vs PCB

MODEL	ABB	POWER SUPPLY	POWER AMP	PREAMP	DISPLAY
KRF-V4530D	E4	-	X07-3142-71	X08-3010-11	X14-7122-72
KRF-V5030D	E1	-	X07-3142-71	X08-3010-11	X14-7122-72
KRF-V5030D	T5	-	X07-3140-51	X08-3010-11	X14-7122-72
KRF-V5030D	Y5	X00-3000-20	X07-3142-91	X08-3010-11	X14-7120-22
KRF-V5030D-S	E3	-	X07-3142-71	X08-3010-11	X14-7122-72
KRF-V5030D-S	15	X00-3000-20	X07-3140-21	X08-3010-11	X14-7120-22
KRF-V5030D-S	M5	X00-3000-20	X07-3140-21	X08-3010-21	X14-7120-22
KRF-V5030D-S	X5	-	X07-3140-71	X08-3010-11	X14-7120-72
KRF-V5030DE	E2	-	X07-3142-71	X08-3010-11	X14-7122-72
VR-405	K5	-	X07-3140-10	X08-3010-10	X14-7120-11
VR-405	P5	-	X07-3140-10	X08-3010-10	X14-7120-11
VR-414	K4	-	X07-3140-11	X08-3010-10	X14-7120-11
VR-414	P4	-	X07-3140-11	X08-3010-10	X14-7120-11
KRF-V6030D	E6	-	X07-3132-72	X08-3010-10	X14-7122-71
KRF-V6030D-S	16	X00-3000-20	X07-3130-22	X08-3010-10	X14-7120-21
KRF-V6030D-S	M6	X00-3000-20	X07-3130-22	X08-3010-21	X14-7120-21
KRF-V6030D-S	X6	-	X07-3130-72	X08-3010-10	X14-7120-71
KRF-V6030DE	E7	-	X07-3132-72	X08-3010-10	X14-7122-71
VR-406	K6	-	X07-3130-11	X08-3010-10	X14-7120-10
VR-406	P6	-	X07-3130-11	X08-3010-10	X14-7120-10



O POWER key (Except for U.S.A. and Canada) Use to turn the main power ON/OFF.

POWER key (For U.S.A. and Canada) Use to turn the power ON/OFF. STANDBY indicator

② ON/STANDBY (I/☉) key (Except for U.S.A. and Canada) Use to switch the power ON/STANDBY when the POWER is turned ON. STANDRY indicator

MULTI CONTROL knob (For VR-407/KRF-V7030D) Used to make a variety of settings.

 MULTI CONTROL keys
 (For VR-406/405/414/KRF-V6030D/V5030D/ V4530D)

Used to make a variety of settings

- SET UP key
- Use to select the surround sound settings.
- Surround indicators DTS indicator
- (For VR-407/KRF-V7030D)
- Lights when the receiver is in the DTS mode.

- DOLBY DIGITAL indicator Lights when the receiver is in the Dolby Digital mode
- PROLOGIC indicator Lights when the receiver is in the PROLOGIC mode.
- 3 STEREO indicator Lights when the receiver is in the 3 STE-REO mode.
- DOWN MIX indicator (For VR-407/KRF-V7030D) Lights when the receiver is in the DOWN
- MIX mode (3) INPUT MODE key

Use to switch between the digital and analog

- DIMMER key Use to adjust the brightness of the display.
- Use to select the REC MODE. MONITOR key
- Use to monitor the source that is connected to the MONITOR jack
- VOLUME CONTROL knob
- @ PHONES jack Use for headphone listening.

SPEAKERS A/B keys (For VR-407/406/KRF-V7030D/V6030D)

Use to turn the A/B speakers ON/OFF. @ SPEAKER KAY

A Numeric keys

A LSTN.M key

SET UP kev

SOUND key

MENU key

ence effects.

MULTI CONTROL keys

P.CALL ⊲/⊳ kevs

@ TUNING 44/PP keys

|◀◀/▶▶| kevs

popent

OSD key

RETURN key

Provide functions identical to those of the

original remote control supplied with the

Use to select the surround sound settings.

Use to adjust the sound quality and ambi-

If tuner is selected as the input source.

If CD or MD is selected as the input source,

Use to operate the tuner or selected com-

these keys function as P.CALL keys.

these keys function as search keys.

component you are controlling.

Use to select the listening mode.

Use to operate other components.

Use to operate other components.

Use to operate other components.

Used to make a variety of settings.

Use to operate other components.


(For VR-405/414/KRF-V5030D/V4530D) Use to turn the speaker ON/OFF. MUTE key

(For VR-405/414/KRF-V5030D/V4530D) Use to temporarily mute the sound. @ SOUND key

- Use to adjust the sound quality and ambience
- BAND key Use to select the broadcast band.
- AUTO key Use to select the auto tuning mode.
- LISTEN MODE key Use to select the listening mode
- MEMORY key Use to store radio stations in the preset
- SOURCE DIRECT key Use to pass the source material direct to the
- INPUT SELECTOR knob
- Use to select the input sources AUX IN S VIDEO/VIDEO/AUDIO L/R

(For VR-407/KRF-V7030D)

Remote control unit (RC-R0609) (VR-407/406/KRF-V7030D/V6030D)



There are some cases in which keys (or knobs) that have the same function on the receiver and on the remote control have different names. In the instructions of this manual, if the names of corresponding keys (or knobs) on the receiver and remote control are different the name of the remote control key is indicated in parenthe-202

B. BOOST key Use to select the maximum adjustment setting for the low frequency range RECEIVER key

Use to return to the operation of the recoiver

O DISC SKIP key

If CD is selected as the input source, this key functions as the multi-CD player disc skip

If TAPE is selected as the input source, this (A and B) of a double cassette deck. +100 kev

Use to select the disc number with the multi-CD player.

TITLE key

Use to operate other components. INPUT SELECTOR keys (DVD, PHONO. CD/DVD TUNER MD/TAPE VIDEO1

VIDEO2, VIDEO3, AV AUX) Selects the inputs and sets the remote control to operate the component registered at the respective input.

MUTE key

Use to temporarily mute the sound. POWER key

Use to turn the receiver on and off POWER key (TV, VCR, DVD, DSS/CDR, CABLE)

Use to turn the other components on and

@ ENTER key

Use to operate other components.

■ kev If tape is selected as the input source, this key functions as the play key for side B of the cassette (the side facing away from the

front of the deck). @ BAND kev

Use to select the broadcast band.

►/II key

If CD is selected as the input source, this key functions as the play/pause key. If MD is selected as the input source, this

key functions as the play key. AUTO key

Use to select the auto tuning mode.

■ key If CD or MD is selected as the input source, this key functions as the stop key

@ II kev

Use to operate other components MINPUT SEL. key

Use to operate other components © CHANNEL △/▽ kevs

Use to select the channel TV SEL. key

Use to operate other components


VOLUME kevs

Use to adjust the receiver volume.

Standby mode

While the standby indicator of the unit is lit, a small amount of current is flowing into the unit's internal circuitry to back up the memory. This condition is referred to as the standby mode of the unit. While the unit is in the standby mode, it can be turned ON from the remote control unit.

Remote control unit (RC-R0509) (VR-405/414/KRF-V5030D/V4530D)



Numeric keys

If CD or MD is selected as the input source. these keys function as numeric keys. If tuner is selected as the input source, these keys are used to call up station presets.

SET UP key

Use to select the surround sound settings. MENU key

Use to operate other components.

SOUND kev

Use to adjust the sound quality and ambience effects OSD key

Use to operate other components.

MULTI CONTROL keys Used to make a variety of settings.

P.CALL ⊲/⊳ keys If tuner is selected as the input source, these keys function as P.CALL keys. l⊲⊲/⊳⊳i keys

If CD or MD is selected as the input source, these keys function as search keys.

If tuner is selected as the input source, these keys function as tuning keys.

6 BASS BOOST key

Use to select the maximum adjustment setting for the low frequency range.

 DISC SKIP key
 If CD is selected as the input source, this key functions as the multi-CD player disc skip

A/B kev

If TAPE is selected as the input source, this (A and B) of a double cassette deck. +100 key

Use to select the disc number with the multi-CD player.

INPUT SELECTOR kevs (DVD. PHONO/ AUX, CD/DVD, TUNER, MD/TAPE, VIDEO1, VIDEO2)

Selects the inputs and sets the remote control to operate the component registered at the respective input.

MUTE key

Use to temporarily mute the sound. @ POWER key

Use to turn the receiver on and off. O DVD key

Used to operate DVD player. For details, refer to the instruction manual

of your DVD player. @ RECEIVER key

Use to return to the operation of the re-

ceiver TITLE key

Use to operate other components.

@ LISTEN MODE key

Use to select the listening mode.

RETURN key

Use to operate other components.

Component operation keys

Use these keys to operate other components with system control connections to the receiver

■ kev

If tape is selected as the input source, this key functions as the play key for side B of the cassette (the side facing away from the front of the deck).

►/II key

If CD is selected as the input source, this key functions as the play/pause key. If MD is selected as the input source, this key

If CD or MD is selected as the input source, this key functions as the stop key.

@ ENTER key

Use to operate other components. BAND key

functions as the play key.


If tuner is selected as the input source, this key functions as the band selector key.

AUTO key

If tuner is selected as the input source, this key functions as the AUTO key.

@ II kev Use to operate other components. @ VOLUME kevs

Use to adjust the receiver volume.



CIRCUIT DESCRIPTION

Pin description of microprocessor: X14,IC1(MN101C35DRA)

	D' N	1	
Pin No.	Pin Name	1/0	Description
1	S. DATA	I/O	Serial data signal.
2	S.BUS	I/O	Serial busy signal.
3	SEL. ST1	0	Strobe output to input selector (IC106).
4	SEL/VOL/PLL DT	0	Data output to selector,volume and PLL IC.
5	SEL/VOL/PLL CLK	0	Clock output to selector, volume and PLL IC.
6	SEL. ST2	0	Strobe 2 output to input selector (IC109).
7	PLL. CE	0	PLL chip enable.
8	Vdd (+5v)	-	Power supply.
9	OSC OUT	0	8MHz clock output.
10	OSC IN	I	8MHz clock input.
11	Vss	-	Connected to ground.
12	X IN	-	Connected to ground.
13	X OUT	-	No used.
14	MMCD	-	Connected to ground.
15	Vref-	-	Connected to ground.
16,17	KEY2,KEY1	I	Input terminal of key1 and key2.
18	MODEL TYPE	ı	Discrimination port of models.
19	TH. SENS	1	No used.
20	PROTECT	Ī	Detection port of protection signal 1.
21	PROTECT2	i	Detection port of protection signal 2.
22	S.LEVEL/CH SPACE	i	RDS S level and channel space changeover.
23	PLL DO	i i	RDS PLL data signal input.
24	Vref+	<u> </u>	Reference voltage of AD converter
25	CE	1	Chip enable.
26	RESET	<u> </u>	Reset signal input.
27	T. MUTE	0	Muting signal output to tuner.
28	RF ST	0	CE signal output of RF receiver IC.
29	RF DT	0	Data signal output of RF receiver IC.
	RF CLK		•
30		0	Clock signal output of RF receiver IC.
31	VOL.ST	0	Latch output of electric volume.
32	DSP INTREQ	I/O	Detection port of DSP INTREQ.
33	DTS DET	- !	Detection port of DTS data.
34	REMOCON	<u> </u>	Remote control signal input.
35	DIR ERR	!	Detection port of DIR error signal.
36	DZF		Detection port of CODEC zero input.
37	RDS.CLK	I	RDS clock input.
38	RDS.DAT/CE2		RDS data input./u-COM chip enable 2.
39	DSP/DIR/CORDEC CDIN	0	Serial data output.
40	DSP/DIR/CDOUT	I	Serial data input.
41	DSP/DIR/CORDEC CCLK	0	Clock output to IC2, IC5 and IC51on X08.
42	DSP CS	0	DSP chip select.
43	DSP PD	0	DSP power down.
44	DIR CODEC CS	0	CODEC chip select.
45	DIR CODEC PD	0	DIR CODEC power down.
46	NO USE	-	No used.
47-57	1G-11G	0	FL grid control(1G-11G).
58-74	P1-P17	0	FL segment control(P1-P17).
75	PACK CONT.	0	Power pack control.
76	LIMMITER	0	Control port of A class power supply.
77	REAR RE	0	Relay control terminal of surround speaker.
78	CENTER RE	0	Relay control terminal of center speaker.
79	FB RE	0	Relay control terminal of front B speaker.
80	FA RE	0	Relay control terminal of front A speaker.
	17111		ready services to make or notice opposition


CIRCUIT DESCRIPTION

Pin No.	Pin Name	I/O	Description
81	POWER RE	0	Power relay control.
82	CS5. 1(DOWN MIX)LED	0	Control terminal of CS5.1(DOWN MIX) LED.
83	3 STEREO LED	0	Control terminal of 3 STEREO LED.
84	DTS LED	0	Control terminal of DTS LED.
85	DOLBY DIGITAL LED	0	Control terminal of DOLBY DIGITAL LED.
86	PROLOGIC LED	0	Control terminal of PROLOGIC LED.
87	STANDBY LED	0	Control terminal of STANDBY LED.
88	PRE OUT MUTE	0	Muting control terminal of pre out.
89	20dB ATT	0	20dB attenuation(volume) control terminal.
90	A.MUTE	0	Audio muting signal output.
91	ABOOT	0	EPROM CS.
92	MULTI. ENC CW	I	Multi cont. encoder signal input(clockwise).
93	MULTI. ENC CCW	I	Multi cont. encoder signal input(counterclockwise).
94	SEL. ENC CW	I	Selector encoder signal input(clockwise).
95	SEL. ENC CCW	I	Selector encoder signal input(counterclockwise).
96	VOL. ENC CW	I	Volume encoder signal input(clockwise).
97	VOL. ENC CCW	I	Volume encoder signal input(counterclockwise).
98	STEREO	ı	Stereo (tuner) signal input.
99	SD	ı	Tuner (SD)detector input.
100	Vpp(-30V)	-	FL power supply(-35V).

ADJUSTMENT

No.	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	RECEIVER SETTINGS	ALIGNMENT POINTS	ALIGN FOR	FIG.
FM	SECTION : EXCEP	T E,T type SELEC	CTOR : FM	•			
1	DISCRIMINATOR (K,P only)	(A) 98.0MHz 1kHz, ±75kHz dev. 70dBf (ANT. input)	Connect a DC voltmeter between CN4 ① and CN4 ② (X07)	98.0MHz	L4 (X07)	0V	
2	TUNING LEVEL	(A) 98.0MHz MONO 1kHz, ±75kHz dev. 29.2dBf (ANT. input)	(B)	MONO 98.0MHz	VR1 (X07)	Adjust VR1 and stop at the point where ED1 (TUNED) goes on.	
FM	SECTION : E,T typ	e only SELECTOR	: FM ※ Adjust	NO.1 and NO.2	? repeat.		
1	DISCRIMINATOR	(A) 98.0MHz 1kHz, ±40kHz dev. 70dBf (ANT. input)	Connect a DC voltmeter between CN4 ① and CN4 ② (X07)	MONO 98.0MHz	L4 (X07)	0V	
2	DISTORTION (MONO)	(A) 98.0MHz 1kHz, ±40kHz dev. MONO 70dBf (ANT. input)	(B)	MONO 98.0MHz	L5 (X07)	Minimum distortion	
3	DISTORTION (STEREO)	(C) 98.0MHz 1kHz,±40kHz dev. Selector : L or R Pilot : ±6kHz dev. 70dBf (ANT. input)	(B)	AUTO 98.0MHz	IFT (FRONT END : A1)	Minimum distortion (L or R)	
4	TUNING LEVEL	(A) 98.0MHz MONO 1kHz, ±40kHz dev. 29.2dBf (ANT. input)	(B)	MONO 98.0MHz	VR1 (X07)	Adjust VR1 and stop at the point where ED1 (TUNED) goes on.	

SYSTEM CONNECTIONS



PARTS DESCRIPTIONS

CAPACITORS

CC 45 TH 1H 220 J 2 3

1 = Type ... ceramic, electrolytic, etc.

4 = Voltage rating

2 = Shape ... round, square, ect.

6 = Tolerance

5 = Value






· Capacitor value

010 = 1pF100 = 10pF

101 = 100pF

 $102 = 1000 pF = 0.001 \mu F$

 $103 = 0.01 \mu F$



· Temperature coefficient

3 = Temp. coefficient

	1st Word	С	L	Р	R	S	Т	U
ſ	Color*	Black	Red	Orange	Yellow	Green	Blue	Violet
ſ	ppm/°C	0	80	-150	-220	-330	-470	-750

2nd Word	G	Н	J	K	L	
ppm/°C ±30		±60	±120	±250	±500	

Example : CC45TH = -470 ± 60 ppm/°C

Tolerance (More than 10pF)

Code	С	D	G	J	K	М	Х	Z	Р	No code
(%)	±0.25	±0.5	±2	±5	±10	±20	+40	+80	+100	More than 10μF – 10 ~ +50
							-20	- 20	-0	Less than 4.7μF -10 ~ +75


(Less than 10pF)

Code	В	С	D	F	G
(pF)	±0.1	±0.25	±0.5	±1	±2

Voltage rating

voitage rating											
2nd word	Α	В	С	D	Е	F	G	Н	J	K	٧
1st word											
0	1.0	1.25	1.6	2.0	2.5	3.15	4.0	5.0	6.3	8.0	-
1	10	12.5	16	20	25	31.5	40	50	63	80	35
2	100	125	160	200	250	315	400	500	630	800	1
3	1000	1250	1600	2000	2500	3150	4000	5000	6300	8000	-

· Chip capacitors



Dimension (Chip capacitors)

	•		
Dimension code	L	W	Т
Empty	5.6 ± 0.5	5.0 ± 0.5	Less than 2.0
Α	4.5 ± 0.5	3.2 ± 0.4	Less than 2.0
В	4.5 ± 0.5	2.0 ± 0.3	Less than 2.0
С	4.5 ± 0.5	1.25 ± 0.2	Less than 1.25
D	3.2 ± 0.4	2.5 ± 0.3	Less than 1.5
E	3.2 ± 0.2	1.6 ± 0.2	Less than 1.25
F	2.0 ± 0.3	1.25 ± 0.2	Less than 1.25
G	1.6 ± 0.2	0.8 ± 0.2	Less than 1.0


RESISTORS

· Chip resistor (Carbon)

(Chip) (B, F)



Dimension



· Carbon resistor (Normal type)

	•		,		-,,,		
(EX)						0 0 0	
	1	2	3	1	5	6	7

1 = Type

5 = Rating wattage

7 = Tolerance


2 = Shape

6 = Value

3 = Dimension

7 = Tolerance


4 = Temp. coefficient




Rating wattage


Code	Wattage	Code	Wattage	Code	Wattage
1J	1/16W	2C	1/6W	3A	1W
2A	1/10W	2E	1/4W	3D	2W
2B	1/8W	2H	1/2W		


X07-3130-10/X07-3140-10 C/3 (J70-1412-11)/(J70-1370-11)





X07 B/3





















AF





АН













ΑE

AG

AM





BC

ΑY


BA


BB

BG

BH

BE





BW

BS

BU

BV

KRF-V4530D/V5030D/V6030D/VR-405/406/414

CA

(KRF-VX030D)

С

707

(VR-4XX)

Parts with exploded numbers larger than 700 are not supplied

ည္ဟ

Α

∌ B or

Bx2 or

Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.



L: Scandinavia

Y: AAFES(Europe)

Y: PX(Far East, Hawaii)

K:USA

T: England

X : Australia

P: Canada

E: Europe

Q: Russia

R: Mexico

H: Korea

G: Germany

C: China

V: China(Shanghai)

I: Malaysia

M: Other Areas ⚠ indicates safety critical components.

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- mark
			KRF-V6030	DD/VR-406 (Y05-4020-10)		
601 601 602 604 605	1A 1A 1A 2B 2A	* * * * *	A01-3733-01 A01-3734-01 A09-1178-08 A46-0309-04 A60-1740-11	METALLIC CABINET METALLIC CABINET BATTERY COVER REAR COVER PANEL	KPE MIX	
605 605 606 606	2A 2A 1A 1A	* * *	A60-1757-11 A60-1758-11 A70-1330-05 A70-1331-05	PANEL PANEL REMOTE CONTROL(RC-R0609) REMOTE CONTROL(RC-R0610)	MIX E KPMIX E	
610 610 611 611 611	2A 2A 2A 2A 2A	* * * * *	B07-2477-02 B07-2478-02 B10-3549-02 B10-3550-02 B10-3551-02	ESCUTCHEON ESCUTCHEON FRONT GLASS FRONT GLASS FRONT GLASS	KPE MIX KP MIX E	
612 613 614 -	2A 2A 2A	* * *	B12-0384-04 B12-0385-04 B43-0314-04 B46-0096-53 B46-0310-03	INDICATOR INDICATOR KENWOOD BADGE WARRANTY CARD WARRANTY CARD	X E	
- - - -			B46-0328-03 B46-0346-00 B46-0347-03 B58-0964-13 B58-0965-13	WARRANTY CARD QUESTIONAIRE CARD WARRANTY CARD CAUTION CARD (UL) CAUTION CARD (PL)	K K P K X	
- - - -		*	B58-0966-13 B58-0967-03 B58-1607-03 B60-4598-00 B60-4599-00	CAUTION CARD (PL) CAUTION CARD (PL) CAUTION CARD INSTRUCTION MANUAL(EN) INSTRUCTION MANUAL(FR)	MIE6 P E7 KPMIX P	
- - - -		* * * * *	B60-4600-00 B60-4602-00 B60-4603-00 B60-4604-00 B60-4605-00	INSTRUCTION MANUAL(TC) INSTRUCTION MANUAL(EN) INSTRUCTION MANUAL(ES) INSTRUCTION MANUAL(FR/GE) INSTRUCTION MANUAL(IT/NE)	MI E7 ME6 E6 E6	
- - - -		* * * * *	B60-4606-00 B60-4607-00 B60-4617-00 B60-4618-00 B60-4619-00	INSTRUCTION MANUAL(RU/PL) INSTRUCTION MANUAL(CZ/HU) INSTRUCTION MANUAL(EN(R)) INSTRUCTION MANUAL(FR(R)) INSTRUCTION MANUAL(ES(R))	E7 E7 KPMIX P M	
- - -		* * *	B60-4620-00 B60-4622-00 B60-4623-00	INSTRUCTION MANUAL(TC(R)) INSTRUCTION MANUAL(5-L(R)) INSTRUCTION MANUAL(5-L(R))	MI E6 E7	
620 621 621 621 622	1A 1B 1B 1B 1A,1B	* *	E03-0115-05 E30-2717-05 E30-2941-05 E30-2942-05 E35-2455-05	AC PLUG ADAPTER AC POWER CORD AC POWER CORD AC POWER CORD FLAT CABLE (21P)	MI X KP MIE	
623 624	2B 1B,2B	*	E35-2456-05 E35-2480-05	FLAT CABLE (33P) FLAT CABLE (23P)		
-		*	G10-0536-04 G11-2416-04	NON-WOVEN FABRIC CUSHION		

L : Scandinavia	K:USA	P: Canada	R: Mexico	C: China	I : Malaysia
Y: PX(Far East, Hawaii)	T: England	E: Europe	G: Germany	V: China(Shanghai)	-
Y : AAFES(Europe)	X : Australia	Q: Russia	H: Korea	M: Other Areas Z	♠ indicates safety critical components.

* New Parts Parts without **Parts No.** are not supplied. Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

8
Re-

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
-		* * *	H10-7628-02 H10-7629-02 H25-0232-04 H25-0391-04 H50-3607-04	POLYSTYRENE FOAMED FIXTURE POLYSTYRENE FOAMED FIXTURE PROTECTION BAG (235X350X0.03) PROTECTION BAG ITEM CARTON CASE	KP	
- - -		* * *	H50-3608-04 H50-3609-04 H50-3610-04 H50-3651-04	ITEM CARTON CASE ITEM CARTON CASE ITEM CARTON CASE ITEM CARTON CASE	E6 X MI E7	
635 636 637 638 639	2C 2B 2B 2B 1B	*	J02-1013-05 J02-1464-03 J19-2808-05 J19-3752-14 J19-5919-05	FOOT FOOT HOLDER UNIT HOLDER UNIT HOLDER	KP	
1 643 −	1B		J42-0083-05 J61-0307-05	POWER CORD BUSHING WIRE BAND		
650 650 651 651 652	2A 2A 2B 2B 2A	* * * * *	K27-2384-04 K27-2385-04 K29-7675-12 K29-7676-12 K29-7678-04	KNOB (BUTTON) KNOB (BUTTON) KNOB KNOB KNOB	E MIX KPE MIX KPE	
652 653 653 654 654	2A 2A 2A 2A 2A	* * * * *	K29-7679-04 K29-7681-14 K29-7682-14 K29-7684-03 K29-7685-03	KNOB KNOB KNOB KNOB KNOB	MIX KPE MIX KPE MIX	
655 655	2A 2A	*	K29-7687-03 K29-7688-03	KNOB KNOB	KPE MIX	
△ 670 △ 670 △ 670 △ 670	1B 1B 1B 1B	* * * *	L07-2787-05 L07-2788-05 L07-2789-05 L07-2790-05	POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER	KP MI X E	
680 681	1A 1A	*	T90-0836-05 T90-0852-05	LEAD WIRE ANTENNA LOOP ANTENNA		
	KRF-\	/50	30D/KRF-V4	530D/VR-405/VR-414 (Y05-405	0-10)	
601 601 601 601 602	1A 1A 1A 1A 1A	* * * * *	A01-3733-01 A01-3733-01 A01-3734-01 A01-3734-01 A09-1178-08	METALLIC CABINET METALLIC CABINET METALLIC CABINET METALLIC CABINET BATTERY COVER	E1E2E4 KPYT E3 MIX	
604 605 605 605 605	2B 2A 2A 2A 2A	* * * * *	A46-0309-04 A60-1759-01 A60-1760-11 A60-1761-11 A60-1761-11	REAR COVER PANEL PANEL PANEL PANEL	KP MIXE3 E1E2E4 YT	
606 606	1A 1A	*	A70-1328-05 A70-1329-05	REMOTE CONTROL(RC-R0509) REMOTE CONTROL(RC-R0510)	KPYMIX ET	
610 610 610 611 611	2A 2A 2A 2A 2A	* * * * *	B07-2477-02 B07-2477-02 B07-2478-02 B10-3552-02 B10-3553-02	ESCUTCHEON ESCUTCHEON ESCUTCHEON FRONT GLASS FRONT GLASS	E1E2E4 KPYT MIXE3 K5P5 YMIX	

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

	Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
	611 611 611 611 612	2A 2A 2A 2A 2A	* * * * *	B10-3574-02 B10-3574-02 B10-3575-02 B10-3605-02 B12-0384-04	FRONT GLASS FRONT GLASS FRONT GLASS FRONT GLASS INDICATOR	E1E2E3 T K4P4 E4	
	613 614 - -	2A 2A	*	B12-0385-04 B43-0314-04 B46-0096-53 B46-0310-03 B46-0328-03	INDICATOR KENWOOD BADGE WARRANTY CARD WARRANTY CARD WARRANTY CARD	X ET KY	
	- - - -			B46-0346-00 B46-0347-03 B58-0513-04 B58-0945-03 B58-0964-13	QUESTIONAIRE CARD WARRANTY CARD CAUTION CARD (PRESET220-240) CAUTION CARD CAUTION CARD (UL)	K P Y T KY	
	- - - -		*	B58-0965-13 B58-0966-13 B58-0966-13 B58-0967-03 B58-1607-03	CAUTION CARD (PL) CAUTION CARD (PL) CAUTION CARD (PL) CAUTION CARD (L) CAUTION CARD	XT E1E3E4 MI P E2	
	- - - -		* * * * *	B59-1104-00 B60-4598-00 B60-4599-00 B60-4600-00 B60-4602-00	SERVICE DIRECTORY INSTRUCTION MANUAL(EN) INSTRUCTION MANUAL(FR) INSTRUCTION MANUAL(TC) INSTRUCTION MANUAL(EN)	Y KPYMIX P MI T1E2	
	- - - -		* * * * *	B60-4603-00 B60-4603-00 B60-4604-00 B60-4605-00 B60-4606-00	INSTRUCTION MANUAL(ES) INSTRUCTION MANUAL(ES) INSTRUCTION MANUAL(FR/GE) INSTRUCTION MANUAL(IT/NE) INSTRUCTION MANUAL(RU/PL)	E1E3E4 M E1E3E4 E1E3E4 E2	
	-		*	B60-4607-00	INSTRUCTION MANUAL(CZ/HU)	E2	
7	620 621 621 621 621	1A 1C 1C 1C 1C	*	E03-0115-05 E30-2605-05 E30-2717-05 E30-2721-05 E30-2941-05	AC PLUG ADAPTER AC POWER CORD AC POWER CORD AC POWER CORD AC POWER CORD	MI Y X T KP	
Ĺ	621 622 623 624	1C 1A,1C 2B,2C 1C,2C	* * *	E30-2942-05 E35-2455-05 E35-2456-05 E35-2480-05	AC POWER CORD FLAT CABLE (21P) FLAT CABLE (33P) FLAT CABLE (23P)	MIE	
	-			G10-0536-04 G11-2416-04	NON-WOVEN FABRIC CUSHION		
	- - - -		*	H10-7628-02 H10-7629-02 H25-0232-04 H25-0232-04 H25-0391-04	POLYSTYRENE FOAMED FIXTURE POLYSTYRENE FOAMED FIXTURE PROTECTION BAG (235X350X0.03) PROTECTION BAG (235X350X0.03) PROTECTION BAG	E KPYMIX	
	- - - -		* * *	H25-0651-04 H50-3611-04 H50-3612-04 H50-3613-04 H50-3614-04	PROTECTION BAG ITEM CARTON CASE	T K5P5 YE1T XE3 MI	
	-		*	H50-3615-04	ITEM CARTON CASE	K4P4	

L : Scandinavia	K:USA	P : Canada	R : Mexico	C : China	I : Malaysia	
			G: Germany	V : China(Shanghai)	• . Malaysia	
Y: AAFES(Europe)	X : Australia	Q: Russia	H: Korea	M: Other Areas	♠ indicates safety critical component	ents .

* New Parts

Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

KRF-V4530D/V5030D/V6030D/VR-405/406/414

Ref. No	Add- ress	New Parts	Parts No.	De	escription		Desti- nation	Re- mark
-		*	H50-3661-04 H50-3734-04	ITEM CARTON CAS			E2 E4	
635 636 637 638 639	2C 2B 2B 2B 2C	*	J02-1013-05 J02-1464-03 J19-2808-05 J19-3752-14 J19-5919-05	FOOT FOOT HOLDER UNIT HOLDER UNIT HOLDER			KP	
643	1C		J42-0083-05 J61-0307-05	POWER CORD BU WIRE BAND	SHING			
650 650 650 651 651	2A 2A 2A 2B 2B	* * * * *	K27-2384-04 K27-2384-04 K27-2385-04 K29-7675-12 K29-7675-12	KNOB (BUTTON) KNOB (BUTTON) KNOB (BUTTON) KNOB KNOB			E1E2E4 YT MIXE3 E1E2E4 KPYT	
651 652 652 652 653	2B 2A 2A 2A 2A	* * * * * *	K29-7676-12 K29-7678-04 K29-7678-04 K29-7679-04 K29-7681-14	KNOB KNOB KNOB KNOB KNOB			MIXE3 E1E2E4 KPYT MIXE3 E1E2E4	
653 653 654 654 654	2A 2A 2A 2A 2A	* * * * *	K29-7681-14 K29-7682-14 K29-7684-03 K29-7684-03 K29-7685-03	KNOB KNOB KNOB KNOB KNOB			KPYT MIXE3 E1E2E4 KPYT MIXE3	
655 655 655	2A 2A 2A	* * *	K29-7687-03 K29-7687-03 K29-7688-03	KNOB KNOB KNOB			E1E2E4 KPYT MIXE3	
4 670 4 670 4 670 4 670 4 670	1C 1C 1C 1C	* * * * *	L07-2794-05 L07-2795-05 L07-2796-05 L07-2797-05 L07-2800-05	POWER TRANSFO POWER TRANSFO POWER TRANSFO POWER TRANSFO POWER TRANSFO	ORMER ORMER ORMER		K5P5 YMI X E K4P4	
680 681	1A 1A	*	T90-0836-05 T90-0852-05	LEAD WIRE ANTEN	NNA			
	F	201	WER SUPPL	Y (X00-3000-2	20) Y,M,I 1	type onl	y	
CN1			E40-8386-05	PIN ASSY				
√ F3			F05-3121-05	FUSE (SEMKO)	(250V T3.15A	AL)		
CN2 ,3			J13-0075-05	FUSE CLIP				
\s1			S62-0001-05	SLIDE SWITCH				
		Ρ	OWER AMP	(X07-3130-11	, X <mark>07-3</mark> 14	10-10)		
C1 C2 C3 C4 C5 ,6			CK73FB1H223K CK73FB1H103K CK73FB1H103K CC73FCH1H331J CK73FB1H103K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.022UF 0.010UF 0.010UF 330PF 0.010UF	K K K J K	ET KPET	
C7 C8 C9 C10 C11 ,12			CE04LW1C470M CK73EB1H103K CC73FCH1H102J CE04LW1C470M CK73FB1H473K	ELECTRO CHIP C CHIP C ELECTRO CHIP C	47UF 0.010UF 1000PF 47UF 0.047UF	16WV K J 16WV K	YMIX MXIY	
L : Scandinav Y : PX(Far Ear Y : AAFES(Eu	st,Hawaii)	Τ:	USA P: Canada England E: Europe Australia Q: Russia	G: Germany V: C	China China(Shanghai) Other Areas 🛕	I: Malaysia	ety critical cor	mponen

* New Parts

Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

	6
	•

Ref. No	Add- ress	New Parts	Parts No.		Description		Desti- nation	Re- marks
C14 C15 C16 C17 C18			CE04LW1C100M CE04LW1H010M CE04RW1HR47M CE04LW1H010M CC73FCH1H470J	ELECTRO ELECTRO ELECTRO ELECTRO CHIP C	10UF 1.0UF 0.47UF 1.0UF 47PF	16WV 50WV 50WV 50WV J		
C19 C20 C21 C22 C23			CE04RW1A100M CK73FB1H473K CE04RW1V3R3M CK73FB1H473K CE04LW1C100M	ELECTRO CHIP C ELECTRO CHIP C ELECTRO	10UF 0.047UF 3.3UF 0.047UF 10UF	10WV K 35WV K 16WV		
C24 C25 C25 C26 C26			CK73FB1H331K CC73FCH1H181J CC73FCH1H471J CK73FB1H183K CK73FB1H223K	CHIP C CHIP C CHIP C CHIP C CHIP C	330PF 180PF 470PF 0.018UF 0.022UF	K J K K	ET KPYMIX ET KPYMIX	
C27 C28 ,29 C30 ,31 C30 ,31 C32			CE04HW1E4R7M CE04LW1H2R2M CK73FB1H223K CK73FB1H333K CE04LW1V4R7M	NP-ELEC ELECTRO CHIP C CHIP C ELECTRO	4.7UF 2.2UF 0.022UF 0.033UF 4.7UF	25WV 50WV K K 35WV	YMIXET KP	
C33 ,34 C35 C36 C37 ,38 C41			CK73FB1H103K CK73FB1H332K CK73FB1H103K CE04LW1C100M CC73FCH1H470J	CHIP C CHIP C CHIP C ELECTRO CHIP C	0.010UF 3300PF 0.010UF 10UF 47PF	K K K 16WV J	YMI KPYMIX	
C42 C43 C44 C45 C46			CC73FCH1H120J CC73FCH1H100D CK73FB1H471K CC73FCH1H220J CE04LW1C100M	CHIP C CHIP C CHIP C CHIP C ELECTRO	12PF 10PF 470PF 22PF 10UF	J D K J 16WV		
C47 C48 C49 C50 C51			CK73FB1H102K CE04LW1C470M CE04LW1H2R2M CC73FCH1H101J CK73FB1H471K	CHIP C ELECTRO ELECTRO CHIP C CHIP C	1000PF 47UF 2.2UF 100PF 470PF	K 16WV 50WV J K		
C52 C70 ,71 C72 C73 C74			CC73FCH1H101J CK73FB1H682K CE04LW1H010M CE04LW1C470M CK73FB1H102K	CHIP C CHIP C ELECTRO ELECTRO CHIP C	100PF 6800PF 1.0UF 47UF 1000PF	J K 50WV 16WV K	ET KP	
C75 C76 C77 C78 C79 ,80			CC73FCH1H030C CC73FCH1H470J CC73FCH1H101J CK73FB1H223K CK73FB1H472K	CHIP C CHIP C CHIP C CHIP C CHIP C	3.0PF 47PF 100PF 0.022UF 4700PF	C J K K	YMI ET	
C81 C82 C83 C84 ,85 C86			CK73FF1C105Z CK73FB1H103K CC73FCH1H101J CK73FB1H223K CK73FB1H471K	CHIP C CHIP C CHIP C CHIP C CHIP C	1.0UF 0.010UF 100PF 0.022UF 470PF	Z K J K K	KPET	
C88 C89 ,90 C91 C101,102 C101,102			CK73FB1H332K CK73FB1H472K CK73FF1C105Z CC73FCH1H221J CC73FCH1H390J	CHIP C CHIP C CHIP C CHIP C CHIP C	3300PF 4700PF 1.0UF 220PF 39PF	K K Z J J	KPYMIX KP	45 6

L: Scandinavia K: USA P: Canada R: Mexico C: China I: Malaysia Y: PX(Far East, Hawaii) V: China(Shanghai) T: England E: Europe G: Germany Y: AAFES(Europe) X : Australia M: Other Areas ▲ indicates safety critical components Q:Russia H: Korea

* New Parts Parts without **Parts No.** are not supplied. Les articles non mentionnes dans le **Parts No.** ne sont pas fournis. Teile ohne **Parts No.** werden nicht geliefert.

Y: PX(Far East, Hawaii)

Y: AAFES(Europe)

T: England

X : Australia

E: Europe

Q:Russia

G: Germany

H: Korea

V: China(Shanghai)

Ref. No	Add- ress	New Parts	Parts No.		Description		Desti- nation	Re- marks
C101,102 C103,104 C103,104 C105,106 C105,106		*	CC73FCH1H390J CE04RW1V100M CE04RW1V100M CC73FCH1H221J CC73FCH1H221J	CHIP C ELECTRO ELECTRO CHIP C CHIP C	39PF 10UF 10UF 220PF 220PF	J 35WV 35WV J J	ETXMIY ETXMIY ETMXIY	5 6 5 6 5
C107,108 C107,108 C109,110 C109,110 C111,112			CE04RW0J470M CE04RW0J470M CC73FCH1H471J CC73FCH1H471J CQ93FMG1H123J	ELECTRO ELECTRO CHIP C CHIP C MYLAR	47UF 47UF 470PF 470PF 0.012UF	6.3WV 6.3WV J J	ETMXIY	6 5 6 5 6
C111,112 C113,114 C113,114 C115,116 C115,116			CQ93FMG1H123J CK45FB1H332K CK45FB1H332K CE04LW1V4R7M CE04LW1V4R7M	MYLAR CERAMIC CERAMIC ELECTRO ELECTRO	0.012UF 3300PF 3300PF 4.7UF 4.7UF	J K K 35WV 35WV	ETMXIY ETMXIY ETMXIY	5 6 5 6 5
C117,118 C117,118 C119-132 C137,138 C139,140			CC45FCH1H101J CC45FCH1H101J CC73FCH1H221J CE04LW1H2R2M CC73FCH1H101J	CERAMIC CERAMIC CHIP C ELECTRO CHIP C	100PF 100PF 220PF 2.2UF 100PF	J J 50WV J	ETMXIY	6 5
C141,142 C143,144 C145,146 C147,148 C149,150			CE04LW1H2R2M CC73FCH1H101J CE04LW1C220M CC73FCH1H471J CE04LW1E470M	ELECTRO CHIP C ELECTRO CHIP C ELECTRO	2.2UF 100PF 22UF 470PF 47UF	50WV J 16WV J 25WV		
C151,152 C153,154 C155,156 C157,158 C159,160			CC73FCH1H100D CE04KW1H100M CE04KW1H2R2M CC73FCH1H102J CK73FB1H222K	CHIP C ELECTRO ELECTRO CHIP C CHIP C	10PF 10UF 2.2UF 1000PF 2200PF	D 50WV 50WV J K		
C161,162 C163,164 C165,166 C167-170 C171,172			CC73FCH1H220J CC73FCH1H102J CE04KW1A101M CK73FF1E104Z CQ93FMG1H472J	CHIP C CHIP C ELECTRO CHIP C MYLAR	22PF 1000PF 100UF 0.10UF 4700PF	J J 10WV Z J		
C175,176 C177,178 C179,180 C181,182 C183,184			CC73FCH1H471J CE04LW1E470M CC73FCH1H100D CE04KW1H100M CE04KW1H2R2M	CHIP C ELECTRO CHIP C ELECTRO ELECTRO	470PF 47UF 10PF 10UF 2.2UF	J 25WV D 50WV 50WV		
C185,186 C187,188 C189,190 C191,192 C193,194			CC73FCH1H102J CK73FB1H222K CC45FCH1H220J CC73FCH1H102J CE04KW1A101M	CHIP C CHIP C CERAMIC CHIP C ELECTRO	1000PF 2200PF 22PF 1000PF 100UF	J K J J 10WV		
C195-198 C199 C200,201 C202 C205			CK73FF1E104Z CQ93FMG1H472J CQ93FMG1H472J CQ93FMG1H472J CC73FCH1H471J	CHIP C MYLAR MYLAR MYLAR CHIP C	0.10UF 4700PF 4700PF 4700PF 470PF	Z J J J		6
C206 C207 C208 C209 C210			CE04LW1E470M CC73FCH1H100D CE04KW1H100M CE04KW1H2R2M CC73FCH1H102J	ELECTRO CHIP C ELECTRO ELECTRO CHIP C	47UF 10PF 10UF 2.2UF 1000PF	25WV D 50WV 50WV J		

Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.



Ref. No	Add- ress	New Parts	Parts No.		Description		Desti- nation	Re- marks
C211 C212 C213 C214 C215,216			CK73FB1H222K CC45FCH1H220J CC73FCH1H102J CE04KW1A101M CK73FF1E104Z	CHIP C CERAMIC CHIP C ELECTRO CHIP C	2200PF 22PF 1000PF 100UF 0.10UF	K J J 10WV Z		
C217 C220 C221 C222 C223			CQ93FMG1H472J CC73FCH1H471J CE04LW1A101M CC73FCH1H101J CE04LW1H100M	MYLAR CHIP C ELECTRO CHIP C ELECTRO	4700PF 470PF 100UF 100PF 10UF	J J 10WV J 50WV		
C224 C225,226 C231,232 C231,232 C231,232		* *	CC73FCH1H221J CK45FF1H103Z C90-3916-05 C90-3916-05 C90-3918-05	CHIP C CERAMIC ELECTRO ELECTRO ELECTRO	220PF 0.010UF 4700UF 4700UF 4700UF	J Z 75WV 75WV 63WV	KP MIXY ET	56
C231,232 C233,234 C233,234 C233,234 C235		* * *	C90-3918-05 C90-3917-05 C90-3917-05 C90-3919-05 CE04KW1E222M	ELECTRO ELECTRO ELECTRO ELECTRO ELECTRO	4700UF 3300UF 3300UF 3300UF 2200UF	63WV 42WV 42WV 35WV 25WV	KP KP MIXY ET	4 56
C236 C237,238 C239 C240 C241			CE04KW1E471M CE04LW1C101M CE04LW1H220M CE04LW1V470M CC45FCH1H101J	ELECTRO ELECTRO ELECTRO ELECTRO CERAMIC	470UF 100UF 22UF 47UF 100PF	25WV 16WV 50WV 35WV J		5 6
C241 C242 C242 C245 C246			CC45FCH1H101J CK45FF1H103Z CK45FF1H103Z CC73FCH1H221J CK45FF1H103Z	CERAMIC CERAMIC CERAMIC CHIP C CERAMIC	100PF 0.010UF 0.010UF 220PF 0.010UF	J Z Z J Z	ETMXIY ETMXIY	5 6 5
C248 C250 C251,252 C253,254 C255,256			CC73FCH1H221J CC73FCH1H102J CE04KW2A100M CE04KW2A101M CE04DW1J101M	CHIP C CHIP C ELECTRO ELECTRO ELECTRO	220PF 1000PF 10UF 100UF 100UF	J J 100WV 100WV 63WV		6
C255,256 C255,256 C259 C260 C261			CE04DW1J101M CE04DW1J101M CE04LW1A101M CE04LW0J221M CE04LW1V4R7M	ELECTRO ELECTRO ELECTRO ELECTRO ELECTRO	100UF 100UF 100UF 220UF 4.7UF	63WV 63WV 10WV 6.3WV 35WV	ETMXIY KP	5 5
C262 C263 C264 C269 C415			CE04LW0J221M CE04LW1V4R7M CE04LW1H010M CK45FE2H103P CE04LW1H010M	ELECTRO ELECTRO ELECTRO CERAMIC ELECTRO	220UF 4.7UF 1.0UF 0.010UF 1.0UF	6.3WV 35WV 50WV P 50WV	KP	4
C416,417 C601 C602 C603 C604			CE04HW1E100M CE04LW1E332M CE04LW1H100M CK45FF1H103Z CE04LW1H100M	NP-ELEC ELECTRO ELECTRO CERAMIC ELECTRO	10UF 3300UF 10UF 0.010UF 10UF	25WV 25WV 50WV Z 50WV		
C605 C606 C606			CE04LW0J222M CK73FB1E104K CK73FB1H683K	ELECTRO CHIP C CHIP C	2200UF 0.10UF 0.068UF	6.3WV K K	YMI KPETX MIY	
CN1			E40-8364-05	PIN ASSY				

: Scandinavia		K:USA	P : Canada	R: Mexico	C: China	I: Malaysia			
: PX(Far East, Hav	vaii)	T: Engla	nd E : Europe	G: Germany	V : China(Shanghai)	·			
: AAFES(Europe)		X : Austr	alia Q : Russia	H: Korea	M: Other Areas	▲ indicates safet	ty critical com	ponents .	

* New Parts

Parts without **Parts No.** are not supplied. Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Y: PX(Far East, Hawaii) T: England E: Europe

X: Australia Q: Russia

Y: AAFES(Europe)

_
n
\mathbf{o}

KRF-V4530D/V5030D/V6030D/VR-405/406/414

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
CN2 CN3 CN4 CN5 CN6		*	E40-8197-05 E40-8485-05 E40-4871-05 E40-9831-05 E40-9848-05	SOCKET FOR PIN ASSY FLAT CABLE CONNECTOR PIN ASSY SOCKET FOR PIN ASSY PIN ASSY	KPET	
CN7 CN61 CN62 CN63 CN64		*	E40-8490-05 E40-4245-05 E40-4245-05 E40-4428-05 E40-4245-05	FLAT CABLE CONNECTOR PIN ASSY PIN ASSY PIN ASSY PIN ASSY	KPETX YMI YMIXET	
CN65 J1 J1 J2 J2		*	E40-8196-05 E70-0049-05 E70-0122-05 E70-0057-05 E70-0065-05	PIN ASSY SCREW TERMINAL BOARD LOCK TERMINAL BOARD LOCK TERMINAL BOARD LOCK TERMINAL BOARD		6 45 6 45
J3 ,4 J7 J8 J8 J61		*	E63-1143-05 E63-1146-05 E20-0321-05 E70-0052-05 E03-0148-05	PIN JACK PIN JACK LOCK TERMINAL BOARD(2P,F) LOCK TERMINAL BOARD AC OUTLET	KPY	
J61 J61 J61 W182			E03-0149-05 E03-0310-05 E03-0325-05 E31-0001-00	AC OUTLET AC OUTLET AC OUTLET JUMPER WIRE	MIE T X	56
F1 F1 F1 F1 F1			F05-2525-05 F05-3121-05 F05-3121-05 F50-0076-05 F50-0077-05	FUSE (SEMKO) (250V T2.5AL) FUSE (SEMKO) (250V T3.15AL) FUSE (SEMKO) (250V T3.15AL) FUSE(5X20) FUSE(5X20)	YMXI ET MIX KP KP	5 6 4 56
F2			F05-2525-05	FUSE (SEMKO) (250V T2.5AL)	E	
CN66,67 CN68,69			J13-0075-05 J13-0075-05	FUSE CLIP FUSE CLIP	E	
CF1 ,2 CF1 ,2 CF1 ,2 CF3 L1		*	L72-0531-05 L72-0536-05 L72-0596-05 L72-0607-05 L39-1384-05	CERAMIC FILTER CERAMIC FILTER CERAMIC FILTER CERAMIC FILTER COMBINATION COIL	YMIX ET KP YMIX	
L2 L3 L4 L4 L5			L40-1091-82 L30-0911-05 L30-0933-05 L30-0950-05 L30-0951-05	SMALL FIXED INDUCTOR(1.0UH) AM IFT FM IFT FM IFT FM IFT	KP ET ET	
L6 ,7 L101-105 T1 T1 T1		* *	L79-1236-05 L39-1373-05 L07-2758-05 L07-2761-05 L07-2805-05	LC FILTER PHASE COMPENSATION COIL POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER	ET KPXET KPXET YMI	
X1			L77-2232-05	CRYSTAL RESONATOR		
R1 R4 R5 R6 R7			RK73FB2A101J RK73FB2A681J RK73FB2A332J RK73FB2A221J RK73FB2A821J	CHIP R 100 J 1/10W CHIP R 680 J 1/10W CHIP R 3.3K J 1/10W CHIP R 220 J 1/10W CHIP R 820 J 1/10W		

G: Germany V: China(Shanghai)

H: Korea

M: Other Areas indicates safety critical components .

* New Parts

Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert

0

ress	New Parts	Parts No.		Description			Desti- nation	Re- marks
		RK73FB2A100J RK73FB2A330J RK73FB2A391J RK73FB2A102J RK73FB2A220J	CHIP R CHIP R CHIP R CHIP R CHIP R	10 33 390 1.0K 22	J	1/10W 1/10W 1/10W 1/10W 1/10W	ET KPYMIX ET	
		RK73FB2A330J RK73FB2A101J RK73FB2A101J RK73FB2A271J RK73FB2A333J	CHIP R CHIP R CHIP R CHIP R CHIP R	33 100 100 270 33K	J	1/10W 1/10W 1/10W 1/10W 1/10W	KPYMIX KPET MIXY ET	
		RK73FB2A472J RK73FB2A220J RK73FB2A362J RK73FB2A302J RK73FB2A822J	CHIP R CHIP R CHIP R CHIP R CHIP R	4.7K 22 3.6K 3.0K 8.2K	J	1/10W 1/10W 1/10W 1/10W 1/10W	KP	
		RK73FB2A392J RK73FB2A153J RK73FB2A332J RK73FB2A912J RK73FB2A163J	CHIP R CHIP R CHIP R CHIP R CHIP R	3.9K 15K 3.3K 9.1K 16K	J	1/10W 1/10W 1/10W 1/10W 1/10W	ET YMIX KP KP	
		RK73FB2A183J RK73FB2A273J RK73FB2A432J RK73FB2A682J RK73FB2A752J	CHIP R CHIP R CHIP R CHIP R CHIP R	18K 27K 4.3K 6.8K 7.5K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	YMIX ET ET KP YMIX	
		RK73FB2A101J RK73FB2A561J RK73FB2A473J RK73FB2A272J RK73FB2A102J	CHIP R CHIP R CHIP R CHIP R CHIP R	100 560 47K 2.7K 1.0K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	YMI YMI YMI KPYMIX	
		RK73FB2A101J RK73FB2A102J RK73FB2A392J RK73FB2A102J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	100 1.0K 3.9K 1.0K 10K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	ET ET ET ET ET	
		RK73FB2A103J RK73FB2A221J RD14NB2E271J RK73EB2B102J RK73FB2A102J	CHIP R CHIP R RD CHIP R CHIP R	10K 220 270 1.0K 1.0K	J J J	1/10W 1/10W 1/4W 1/8W 1/10W		
		RK73EB2B102J RK73FB2A102J RK73FB2A103J RD14NB2E471J RK73FB2A562J	CHIP R CHIP R CHIP R RD CHIP R	1.0K 1.0K 10K 470 5.6K	J J J	1/8W 1/10W 1/10W 1/4W 1/10W		
		RK73FB2A101J RK73FB2A222J RK73FB2A102J RK73FB2A333J RK73FB2A102J	CHIP R CHIP R CHIP R CHIP R CHIP R	100 2.2K 1.0K 33K 1.0K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W		
		RK73FB2A123J RK73FB2A122J RK73FB2A153J RK73FB2A392J RK73FB2A822J	CHIP R CHIP R CHIP R CHIP R CHIP R	12K 1.2K 15K 3.9K 8.2K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	KP ET YMIX	
			RK73FB2A330J RK73FB2A391J RK73FB2A310J RK73FB2A102J RK73FB2A101J RK73FB2A101J RK73FB2A101J RK73FB2A271J RK73FB2A220J RK73FB2A333J RK73FB2A332J RK73FB2A362J RK73FB2A362J RK73FB2A362J RK73FB2A362J RK73FB2A362J RK73FB2A392J RK73FB2A392J RK73FB2A392J RK73FB2A332J RK73FB2A163J RK73FB2A163J RK73FB2A163J RK73FB2A63J RK73FB2A63J RK73FB2A62J RK73FB2A103J RK73FB2A61J RK73FB2A61J RK73FB2A103J RK73FB2A102J RK73FB2A102J RK73FB2A103J RK73FB2A103J RK73FB2A103J RK73FB2A102J RK73FB2A103J RK73FB2A102J RK73FB2A103J RK73FB2A102J RK73FB2A103J RK73FB2A102J	RK73FB2A330J CHIP R RK73FB2A30J CHIP R RK73FB2A102J CHIP R RK73FB2A330J CHIP R RK73FB2A330J CHIP R RK73FB2A330J CHIP R RK73FB2A330J CHIP R RK73FB2A310J CHIP R RK73FB2A333J CHIP R RK73FB2A32J CHIP R RK73FB2A320J CHIP R RK73FB2A302J CHIP R RK73FB2A4012J CHIP R RK73FB2A402J CHIP R RK73FB2A402J CHIP R RK73FB2A403J CHIP R RK73FB2A403J CHIP R RK73FB2A403J CHIP R RK73FB2A102J CHIP R RK73FB2A103J CHIP R RK73FB2A103J CHIP R RK73FB2A102J CHIP R RK73FB2A103J CHIP R RK73FB2A102J CHIP R RK73FB2A103J CHIP R	RK73FB2A330_J CHIP R 390 RK73FB2A391_J CHIP R 390 RK73FB2A391_J CHIP R 1.0K RK73FB2A102_J CHIP R 22 RK73FB2A330_J CHIP R 100 RK73FB2A101_J CHIP R 100 RK73FB2A101_J CHIP R 100 RK73FB2A271_J CHIP R 270 RK73FB2A271_J CHIP R 270 RK73FB2A272_J CHIP R 270 RK73FB2A220_J CHIP R 222 RK73FB2A302_J CHIP R 3.0K RK73FB2A302_J CHIP R 15K RK73FB2A302_J CHIP R 15K RK73FB2A302_J CHIP R 15K RK73FB2A302_J CHIP R 16K RK73FB2A30_J CHIP R 16K RK73FB2A30_J CHIP R 16K RK73FB2A30_J CHIP R 16K RK73FB2A163_J CHIP R 27K RK73FB2A30_J CHIP R 4.3K RK73FB2A30_J CHIP R 4.3K RK73FB2A30_J CHIP R 100 RK73FB2A30_J CHIP R 100 RK73FB2A30_J CHIP R 100 RK73FB2A30_J CHIP R 100 RK73FB2A10_J CHIP R 100 RK73FB2A10_J CHIP R 1.0K RK73FB2A33_J CHIP R	RK73FB2A330J CHIP R 390 J RK73FB2A102J CHIP R 1.0K J CHIP R 1.0K J RK73FB2A102J CHIP R 1.0K J RK73FB2A30J CHIP R 1.0K J RK73FB2A101J CHIP R 1.0D J RK73FB2A101J CHIP R 1.0D J RK73FB2A101J CHIP R 1.0D J RK73FB2A303J CHIP R 270 J RK73FB2A303J CHIP R 270 J RK73FB2A303J CHIP R 220 J RK73FB2A362J CHIP R 22 J RK73FB2A362J CHIP R 3.0K J RK73FB2A302J CHIP R 3.0K J RK73FB2A302J CHIP R 3.0K J RK73FB2A302J CHIP R 3.9K J RK73FB2A302J CHIP R 3.9K J RK73FB2A102J CHIP R 3.3K J RK73FB2A102J CHIP R 3.3K J RK73FB2A163J CHIP R 3.3K J RK73FB2A163J CHIP R 3.3K J RK73FB2A163J CHIP R 1.0K J RK73FB2A682J CHIP R 3.3K J RK73FB2A682J CHIP R 27K J RK73FB2A102J CHIP R 1.0K J RK73FB2A122J CHIP R 1.0K J RK73FB2A122J CHIP	RK73FB2A330J CHIP R 390 J 1/10W RK73FB2A102J CHIP R 1.0K J 1/10W RK73FB2A102J CHIP R 22 J 1/10W RK73FB2A30J CHIP R 22 J 1/10W RK73FB2A30J CHIP R 30 J 1/10W RK73FB2A101J CHIP R 100 J 1/10W RK73FB2A101J CHIP R 100 J 1/10W RK73FB2A101J CHIP R 100 J 1/10W RK73FB2A271J CHIP R 100 J 1/10W RK73FB2A32J CHIP R 270 J 1/10W RK73FB2A472J CHIP R 270 J 1/10W RK73FB2A20J CHIP R 22 J 1/10W RK73FB2A362J CHIP R 22 J 1/10W RK73FB2A362J CHIP R 3.0K J 1/10W RK73FB2A362J CHIP R 3.0K J 1/10W RK73FB2A362J CHIP R 3.0K J 1/10W RK73FB2A362J CHIP R 3.9K J 1/10W RK73FB2A362J CHIP R 3.9K J 1/10W RK73FB2A163J CHIP R 15K J 1/10W RK73FB2A682J CHIP R 3.9K J 1/10W RK73FB2A103J CHIP R 15K J 1/10W RK73FB2A103J CHIP R 15K J 1/10W RK73FB2A662J CHIP R 3.0K J 1/10W RK73FB2A663J CHIP R 15K J 1/10W RK73FB2A663J CHIP R 15K J 1/10W RK73FB2A610J CHIP R 100 J 1/10W RK73FB2A610J CHIP R 1.0K J 1/10W RK73FB2A10J CHIP R 1.0K J	RK73FB2A330J CHIP R 390 J 1/10W RK73FB2A102J CHIP R 1.0K J 1/10W RK73FB2A102J CHIP R 22 J 1/10W ET RK73FB2A330J CHIP R 330 J 1/10W KPYMIX RK73FB2A330J CHIP R 33 J 1/10W KPYMIX RK73FB2A101J CHIP R 100 J 1/10W KPYMIX RK73FB2A101J CHIP R 100 J 1/10W KPT RK73FB2A101J CHIP R 270 J 1/10W KPT RK73FB2A271J CHIP R 270 J 1/10W RK73FB2A330J CHIP R 33K J 1/10W ET RK73FB2A330J CHIP R 22 J 1/10W RK73FB2A32DJ CHIP R 22 J 1/10W RK73FB2A32DJ CHIP R 3.6K J 1/10W RK73FB2A32DJ CHIP R 3.6K J 1/10W RK73FB2A32DJ CHIP R 3.9K J 1/10W RK73FB2A32DJ CHIP R 3.9K J 1/10W RK73FB2A32DJ CHIP R 3.9K J 1/10W RK73FB2A32DJ CHIP R 3.3K J 1/10W RK73FB2A32DJ CHIP R 3.4K J 1/10W RK73FB2A32DJ CHIP R 4.4K J 1/10W RK73FB2A473J CHIP R 4.4K J 1/10W RK73FB2A473J CHIP R 560 J 1/10W RK73FB2A473J CHIP R 560 J 1/10W RK73FB2A473J CHIP R 1.0K J 1/10W RK73FB2A473J CHIP R 1.0K J 1/10W RK73FB2A473J CHIP R 1.0K J 1/10W RK73FB2A10J CH

L : Scandinavia	K:USA	P: Canada	R: Mexico	C: China	I: Malaysia	
Y: PX(Far East, Hawaii)	T: England	E: Europe	G: Germany	V: China(Shanghai)	*	
Y: AAFES(Europe)	X : Australia	Q: Russia	H: Korea	M: Other Areas		y critical components.

* New Parts Parts without **Parts No.** are not supplied. Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

Y: PX(Far East, Hawaii) T: England

X : Australia

Y: AAFES(Europe)

E: Europe

Q: Russia

G: Germany

H: Korea

V: China(Shanghai)

M: Other Areas ▲ indicates safety critical components.

@

	Ref. N	0	Add- ress	New Parts	Parts No.		Description			Desti- nation	Re- marks
	R74 R75 R76 R78 R79				RK73FB2A473J RK73FB2A822J RK73FB2A182J RK73FB2A821J RK73FB2A102J	CHIP R CHIP R CHIP R CHIP R CHIP R	47K 8.2K 1.8K 820 1.0K]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
⚠	R80 R81 R82 R83 R84				RK73FB2A223J RS14KB3A820J RK73FB2A272J RK73FB2A102J RK73EB2B102J	CHIP R FL-PROOF RS CHIP R CHIP R CHIP R	22K 82 2.7K 1.0K 1.0K]]]	1/10W 1W 1/10W 1/10W 1/8W	ET ET	
	R85 -87 R88 R89 R101,10 R101,10				RK73FB2A105J RK73FB2A563J RK73FB2A333J RK73FB2A102J RK73FB2A102J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.0M 56K 33K 1.0K 1.0K]]]	1/10W 1/10W 1/10W 1/10W 1/10W	ETMXIY	6 5
	R103,10 R103,10 R105,10 R105,10 R115,11	14 16 16			RK73FB2A273J RK73FB2A273J RK73FB2A101J RK73FB2A101J RD14BB2C102J	CHIP R CHIP R CHIP R CHIP R RD	27K 27K 100 100 1.0K]]]	1/10W 1/10W 1/10W 1/10W 1/6W	ETMXYI ETMXIY KP	6 5 6 5 45
	R117,11 R119,12 R121,12 R123,12 R125,12	20 22 24			RK73FB2A102J RK73FB2A224J RK73FB2A102J RK73FB2A224J RK73FB2A102J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.0K 220K 1.0K 220K 1.0K]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
	R127,12 R129,13 R131,13 R133,13 R135,13	30 32 34			RK73FB2A224J RK73FB2A102J RK73FB2A224J RK73FB2A102J RK73FB2A224J	CHIP R CHIP R CHIP R CHIP R CHIP R	220K 1.0K 220K 1.0K 220K]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
	R137,13 R139,14 R141,14 R143,14 R153-15	0 2 4			RK73FB2A102J RK73FB2A224J RK73FB2A102J RK73FB2A224J RK73FB2A224J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.0K 220K 1.0K 220K 220K]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
	R159 R161,16 R163,16 R165,16 R167,16	66			RK73FB2A562J RK73FB2A302J RK73FB2A682J RK73FB2A183J RK73FB2A182J	CHIP R CHIP R CHIP R CHIP R CHIP R	5.6K 3.0K 6.8K 18K 1.8K]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
	R169,17 R171,17 R173,17 R175,17 R177,17	2 4 6			RK73FB2A224J RK73FB2A183J RK73FB2A222J RK73FB2A104J RK73FB2A563J	CHIP R CHIP R CHIP R CHIP R CHIP R	220K 18K 2.2K 100K 56K]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
	R179 R180 R181-18 R185,18 R187,18	6			RK73FB2A102J RK73EB2B102J RS14KB3DR22J RK73FB2A563J RK73FB2A182J	CHIP R CHIP R FL-PROOF RS CHIP R CHIP R	1.0K 1.0K 0.22 56K 1.8K]]]	1/10W 1/8W 2W 1/10W 1/10W	KPMXI	6
	R187,18 R187,18 R187,18 R187,18 R189,19	88 88 88			RK73FB2A222J RK73FB2A242J RK73FB2A272J RK73FB2A272J RS14KB3D120J	CHIP R CHIP R CHIP R CHIP R FL-PROOF RS	2.2K 2.4K 2.7K 2.7K 12]]]	1/10W 1/10W 1/10W 1/10W 2W	KPMXIY E ET KP	5 6 5 4
	L : Scandir				USA P: Canada		: China		: Malaysia		

Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.



Les articles	non me	ntion	are not supplied. Ines dans le Parts N Irden nicht geliefert.	o. ne sont pas fou	urnis.				0
Ref. No	Add- ress	New Parts	Parts No.		Description			Desti- nation	Re- marks
R191,192 R199,200 R201,202 R203,204 R203,204			R\$14KB3D391J RK73FB2A333J RK73FB2A303J RK73FB2A113J RK73FB2A113J	FL-PROOF RS CHIP R CHIP R CHIP R CHIP R	390 33K 30K 11K 11K	J J J	2W 1/10W 1/10W 1/10W 1/10W	ETMIXY KP	5 5
R203,204 R203,204 R205,206 R209,210 R211,212			RK73FB2A153J RK73FB2A912J RK73FB2A471J RK73FB2A102J RK73FB2A273J	CHIP R CHIP R CHIP R CHIP R CHIP R	15K 9.1K 470 1.0K 27K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	KP	4 6
R213,214 R215,216 R217,218 R219,220 R221,222			RK73FB2A182J RK73FB2A224J RK73FB2A183J RK73EB2B222J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.8K 220K 18K 2.2K 100K	J J J	1/10W 1/10W 1/10W 1/8W 1/10W		
R223,224 R225 R227-230 R233,234 R233,234			RK73FB2A563J RK73FB2A102J RS14KB3DR22J RK73FB2A182J RK73FB2A222J	CHIP R CHIP R FL-PROOF RS CHIP R CHIP R	56K 1.0K 0.22 1.8K 2.2K	J J J	1/10W 1/10W 2W 1/10W 1/10W	KPMXI KPMXIY	6 5
R233,234 R233,234 R233,234 R235,236 R243,244			RK73FB2A242J RK73FB2A272J RK73FB2A272J RS14KB3D120J RK73FB2A333J	CHIP R CHIP R CHIP R FL-PROOF RS CHIP R	2.4K 2.7K 2.7K 12 33K	J	1/10W 1/10W 1/10W 2W 1/10W	E ET KP	6 5 4
R245,246 R247,248 R247,248 R247,248 R247,248			RK73FB2A303J RK73FB2A113J RK73FB2A113J RK73FB2A153J RK73FB2A912J	CHIP R CHIP R CHIP R CHIP R CHIP R	30K 11K 11K 15K 9.1K	J	1/10W 1/10W 1/10W 1/10W 1/10W	ETMXIY KP KP	5 5 4 6
R249,250 R251 R252 R253 R254			RK73FB2A471J RK73FB2A183J RK73FB2A182J RK73FB2A224J RK73FB2A183J	CHIP R CHIP R CHIP R CHIP R CHIP R	470 18K 1.8K 220K 18K	J J	1/10W 1/10W 1/10W 1/10W 1/10W		
R256 R257 R259,260 R262 R262			RK73FB2A104J RK73FB2A563J RS14KB3DR22J RK73FB2A182J RK73FB2A222J	CHIP R CHIP R FL-PROOF RS CHIP R CHIP R	100K 56K 0.22 1.8K 2.2K	J J J	1/10W 1/10W 2W 1/10W 1/10W	KPMXI KPMXIY	6 5
R262 R262 R262 R263 R267			RK73FB2A242J RK73FB2A272J RK73FB2A272J RS14KB3D120J RK73FB2A303J	CHIP R CHIP R CHIP R FL-PROOF RS CHIP R	2.4K 2.7K 2.7K 12 30K	J J J	1/10W 1/10W 1/10W 2W 1/10W	E ET KP	6 5 4
R268 R268 R268 R268 R269			RK73FB2A113J RK73FB2A113J RK73FB2A153J RK73FB2A912J RK73FB2A471J	CHIP R CHIP R CHIP R CHIP R CHIP R	11K 11K 15K 9.1K 470	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	ETMXIY KP KP	5 5 4 6
R270 R271 R272 R273 R274			RK73FB2A333J RK73FB2A183J RK73FB2A241J RK73FB2A332J RK73FB2A183J	CHIP R CHIP R CHIP R CHIP R CHIP R	33K 18K 240 3.3K 18K)))	1/10W 1/10W 1/10W 1/10W 1/10W		

L : Scandinavia	K:USA	P : Canada	R: Mexico	C: China	I : Malaysia	
Y: PX(Far East, Hawaii) Y: AAFES(Europe)	T : England X : Australia	E : Europe Q : Russia	G : Germany H : Korea	V: China(Shanghai) M: Other Areas	▲ indicates safet	y critical components .

* New Parts

L: Scandinavia

Y: AAFES(Europe)

Y: PX(Far East, Hawaii)

K: USA

T: England

X : Australia

P: Canada

E: Europe

Q:Russia

R: Mexico

H: Korea

G: Germany

C: China

V: China(Shanghai)

I: Malaysia

M: Other Areas indicates safety critical components.

Parts without **Parts No.** are not supplied. Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

	Ref. No	Add-	New	Parts No.	De	escription			Desti-	Re-
	R276 R277 R278 R279,280 R279,280	ress	Parts	RK73FB2A224J RK73FB2A331J RK73FB2A102J R92-1955-05 R92-1956-05	CHIP R CHIP R CHIP R METAL GLAZE METAL GLAZE	220K 330 1.0K 10K 33K	J J J	1/10W 1/10W 1/10W 1/4W 1/4W	KP	marks 4 6
Δ Δ	R279,280 R279,280 R281 R283		* *	R92-1956-05 R92-1956-05 R92-1945-05 RK73FB2A1R0J RK73FB2A1R0J	METAL GLAZE METAL GLAZE METAL GLAZE CHIP R CHIP R	33K 33K 1 1	J	1/4W 1/4W 1/4W 1/10W 1/10W	ETMXIY KP	5 5 6 5
Δ	R284		*	RK73FB2A1R0J RK73FB2A104J R92-1945-05 RK73EB2B101J RK73FB2A513J	CHIP R CHIP R METAL GLAZE CHIP R CHIP R	1 100K 1 100 51K	J J J	1/10W 1/10W 1/4W 1/8W 1/10W	KP KP	5
	R303-306 R303-306 R303-306 R307 R307			RS14KB3A392J RS14KB3A392J RS14KB3A392J RK73EB2B273J RK73EB2B273J	FL-PROOF RS FL-PROOF RS FL-PROOF RS CHIP R CHIP R	3.9K 3.9K 3.9K 27K 27K	J J J	1W 1W 1W 1/8W 1/8W	ETMXIY KP ETMXIY	6 5 5 6 5
Δ	R307 R308 R308 R308 R309,310			RK73EB2B273J RK73FB2A273J RK73FB2A273J RK73FB2A273J RK73FB2A1R0J	CHIP R CHIP R CHIP R CHIP R CHIP R	27K 27K 27K 27K 1	J J J	1/8W 1/10W 1/10W 1/10W 1/10W	KP ETMXIY KP	5 6 5 5 6
Δ Δ	R309,310 R312 R313,314			RK73FB2A1R0J RK73FB2A1R0J RD14NB2E103J RK73FB2A473J RK73FB2A1R0J	CHIP R CHIP R RD CHIP R CHIP R	1 1 10K 47K 1	J J J	1/10W 1/10W 1/4W 1/10W 1/10W	ETMXIY KP	5 5
⚠	R316 R317 R320 R322 R323			RD14NB2E101J RD14BB2C752J RK73FB2A103J RD14BB2C103J RK73FB2A393J	RD RD CHIP R RD CHIP R	100 7.5K 10K 10K 39K	J J J	1/4W 1/6W 1/10W 1/6W 1/10W		45
	R324,325 R324,325 R324,325 R324,325 R326-328			RK73FB2A104J RK73FB2A204J RK73FB2A753J RK73FB2A753J RK73FB2A473J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K 200K 75K 75K 47K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	ET KP KPMXIY	5 4 6 5
	R329 R330 R331 R332 R333			RK73FB2A123J RK73FB2A153J RK73FB2A332J RK73FB2A682J RK73FB2A223J	CHIP R CHIP R CHIP R CHIP R CHIP R	12K 15K 3.3K 6.8K 22K	J	1/10W 1/10W 1/10W 1/10W 1/10W		
	R334 R335 R336 R337 R339,340			RK73FB2A123J RK73FB2A153J RK73FB2A332J RK73FB2A682J RK73FB2A472J	CHIP R CHIP R CHIP R CHIP R CHIP R	12K 15K 3.3K 6.8K 4.7K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W		
1	R342-344 R347 R349 R350		*	R92-1945-05 RS14KB3A151J RS14KB3D4R7J RS14KB3A4R7J RK73FB2A1R0J	METAL GLAZE FL-PROOF RS FL-PROOF RS FL-PROOF RS CHIP R	1 150 4.7 4.7 1	J J J	1/4W 1W 2W 1W 1/10W		6
Λ	R350			RK73FB2A1R0J	CHIP R	1	J	1/10W	ETMXIY	5

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.



R	Ref. No	Add- ress	New Parts	Parts No.	De	scription			Desti- nation	Re
R3 R3 R3 R3 R3	351 352			RK73FB2A1R0J RK73FB2A103J RK73FB2A223J RK73FB2A102J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	1 10K 22K 1.0K 10K	J J	1/10W 1/10W 1/10W 1/10W 1/10W	KP	5
R3 R3	360 361,362 363 370 371			RK73FB2A103J RK73FB2A473J RK73FB2A361J RK73FB2A102J RK73FB2A563J	CHIP R CHIP R CHIP R CHIP R CHIP R	10K 47K 360 1.0K 56K]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
R3 R3 R3	372 373 375 377,378			RK73FB2A104J RK73FB2A361J RK73FB2A102J RK73FB2A102J RK73EB2B102J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K 360 1.0K 1.0K 1.0K	J J J	1/10W 1/10W 1/10W 1/10W 1/8W		
R3 R3 R3				RK73FB2A473J RK73FB2A472J RK73FB2A473J RK73FB2A470J RD14NB2E1R0J	CHIP R CHIP R CHIP R CHIP R RD	47K 4.7K 47K 47	J J J	1/10W 1/10W 1/10W 1/10W 1/4W		
R6 R6 R6 R6	604 604 609			RD14NB2E1R0J RD14NB2E100J RD14NB2E390J RD14NB2E151J RD14NB2E181J	RD RD RD RD RD	1 10 39 150 180]]]	1/4W 1/4W 1/4W 1/4W 1/4W	KP XET ET X	
R6 R6 R6 VR	609 610			RD14NB2E2R2J RD14NB2E270J R92-1844-05 R32-0037-05 R92-0670-05	RD RD CARBON SEMI FIXED VARIA CHIP R	2.2 27 3.3M BLE RESIS 0 OHM	J J STOR	1/4W 1/4W 1/2W	YMI KP KP	
W3 W3 W3	262 301 302 303-306 307			R92-0670-05 R92-0679-05 R92-0670-05 R92-0679-05 R92-0670-05	CHIP R CHIP R CHIP R CHIP R CHIP R	0 OHM 0 OHM 0 OHM 0 OHM 0 OHM				
W: W: W:	308 309-311 312 313 315-318			R92-0679-05 R92-0670-05 R92-0679-05 R92-0670-05 R92-0679-05	CHIP R CHIP R CHIP R CHIP R CHIP R	0 OHM 0 OHM 0 OHM 0 OHM 0 OHM				
W3 W3 W3	319,320 321 322,323 324-333 334,335			R92-0670-05 R92-0679-05 R92-0670-05 R92-0679-05 R92-0670-05	CHIP R CHIP R CHIP R CHIP R CHIP R	0 OHM 0 OHM 0 OHM 0 OHM 0 OHM			KP	45
W: W: W:	336 337,338 338,339 338,339 340,341			R92-0679-05 R92-0670-05 R92-0670-05 R92-0670-05 R92-0679-05	CHIP R CHIP R CHIP R CHIP R CHIP R	0 OHM 0 OHM 0 OHM 0 OHM 0 OHM			KP XYEMTI	45 6 5
W5 W5 W5	342,343 506 513,514 523 651-655			R92-0670-05 R92-0679-05 R92-0679-05 R92-0679-05 R92-0670-05	CHIP R CHIP R CHIP R CHIP R CHIP R	0 OHM 0 OHM 0 OHM 0 OHM 0 OHM				

L : Scandinavia		K:USA	P: Canada	R: Mexico	C: China	I: Malaysia		
Y: PX(Far East, H	lawaii)	T : England	E : Europe	G: Germany	V : China(Shanghai)	-		
V · A AFFS/Furon	(۵	Y · Δustralia	∩ · Russia	H · Korea	M · Other Areas	♠ indicatos safot	v critical com	nonents

* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis. Telle ohne **Parts No.** werden nicht geliefert.

@

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marl
W656 W659 W660 W662 W680			R92-0670-05 R92-0670-05 R92-0670-05 R92-0670-05 R92-0679-05	CHIP R 0 OHM	YMI	6
W683 W683 W683 W683 W683			R92-0679-05 R92-0679-05 R92-0679-05 R92-0679-05 R92-0679-05	CHIP R 0 OHM	IX KP KP KPM MIX	6 5 4 6 5
W684,685			R92-0679-05	CHIP R 0 OHM		
K1 ,2 K3 K4 K601 K601			\$76-0042-05 \$76-0042-05 \$76-0042-05 \$76-0099-05 \$76-0099-05	MAGNETIC RELAY MAGNETIC RELAY MAGNETIC RELAY MAGNETIC RELAY MAGNETIC RELAY	KP	6 5 6
K601 S1		*	S76-0107-05 S62-0034-05	MAGNETIC RELAY SLIDE SWITCH	EMXI YMI	5
D1 D101 D102 D103 D103			UDZ3.3B D5SBA20F03 S1ZB20(4101) D5SBA20F03 D5SBA20F03	ZENER DIODE DIODE DIODE DIODE DIODE DIODE	KP XY	56
D103 D104 D104 D105 D105			RBV-602LFA HZS16N(B2) MTZJ16(B) HZS15N(B2) MTZJ15(B)	DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	ЕТМІ	
D106,107 D108 D108 D108 D108			MA111 UDZ3.3B UDZ5.6B UDZ6.2B UDZ6.8B	DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	KP ET E KPMXIY	5 6 5
D108 D109 D109 D109 D109			UDZ8.2B UDZ10B UDZ11B UDZ13B UDZ13B	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	KPMXI E ET KP MI	6 6 5 4 5
D109 D109 D110 D110 D110			UDZ15B UDZ16B UDZ10B UDZ13B UDZ13B	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	KPMXI KPMXIY ET E KP	6 5 5 6 4
D110 D110 D111-115 D117-120 D117-120			UDZ13B UDZ16B MA111 UDZ15B UDZ15B	ZENER DIODE ZENER DIODE DIODE ZENER DIODE ZENER DIODE	KPMXIY KPMXI	5 6 6 5
D117-120 D121 D122 D123 D123			UDZ15B MA111 UDZ3.9B HSS104A 1SS133	ZENER DIODE DIODE ZENER DIODE DIODE DIODE	KP	5

L : Scandinavia	K:USA	P: Canada	R: Mexico	C : China	I : Malaysia
Y: PX(Far East, Hawaii)	T: England	E : Europe	G: Germany	V: China(Shanghai)	-
Y: AAFES(Europe)	X : Australia	Q: Russia	H: Korea	M: Other Areas	▲ indicates safety critical components.

Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Taila ohne **Parts No.** worden nicht geliefert



Ø

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis. Teile ohne **Parts No.** werden nicht geliefert.



Ref. No	Add- ress	New Parts	Parts No.		Description		Desti- nation	Re- marl
Q51 -53 Q54 Q113-117 Q118 Q118			2SB1218A(Q,R) 2SB1640 2SC3906K 2SA1576A(R,S) 2SB1218A(Q,R)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR				
Q119,120 Q121 Q121 Q122,123 Q132			2SC3906K 2SA1576A(R,S) 2SB1218A(Q,R) 2SC1845(F,E) 2SC3906K	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR				
Q133 Q134 Q135 Q135 Q136			2SB1566 2SC1845(F,E) 2SA1576A(R,S) 2SB1218A(Q,R) UN5219	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRAI				
Q137 Q138 Q139,140 Q141 Q142			2SD2395 2SB1640 DTC123JUA DTC123JUA DTC123JUA	TRANSISTOR TRANSISTOR DIGITAL TRAI DIGITAL TRAI DIGITAL TRAI	NSISTOR NSISTOR			6
Q201 Q201 Q202 Q202 Q203,204			2SC4081(R,S) 2SD1819A(Q,R) 2SA1576A(R,S) 2SB1218A(Q,R) 2SC4081(R,S)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR			YMI	
Q203,204 Q206,207 Q206,207 Q210,211 Q212			2SD1819A(Q,R) 2SC4081(R,S) 2SD1819A(Q,R) 2SD1757K 2SA1576A(R,S)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR			YMI ET ET	
Q212 Q214 Q214 Q601 Q601			2SB1218A(Q,R) 2SA1576A(R,S) 2SB1218A(Q,R) 2SC1740S(Q,R) 2SC2785(F,E)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR				
A1 A1			W02-2584-05 W02-2622-05	FM FRONT-EI			ET KPYMIX	
			PREA	AMP (X08-	-3010-10)			
C1 ,2 C3 C4 C5 ,6 C7 ,8			CE04RW1C100M CK73FB1H103K CC73FCH1H101J CK73FB1H222K CK73FB1E104K	ELECTRO CHIP C CHIP C CHIP C CHIP C	10UF 0.010UF 100PF 2200PF 0.10UF	16WV K J K K		
C9 ,10 C21 C22 C23 C24 ,25			CE04RW1C4R7M CK73FB1E104K CE04LW1H100M CK73FB1H102K CK73FB1E104K	ELECTRO CHIP C ELECTRO CHIP C CHIP C	4.7UF 0.10UF 10UF 1000PF 0.10UF	16WV K 50WV K K		
C26 C27 C29 C31 C32		*	CK73FF1C105Z C91-1597-05 CK73FB1H103K CC73FCH1H220J CK73FB1H472K	CHIP C CERAMIC CHIP C CHIP C CHIP C	1.0UF 4.7UF 0.010UF 22PF 4700PF	Z Z K J K		
C33			CC73FCH1H220J	CHIP C	22PF	J		
L : Scandinav Y : PX(Far Eas Y : AAFES(Eu	st,Hawaii)	T:	USA P: Canada England E: Europe Australia Q: Russia	R: Mexico G: Germany H: Korea	C: China V: China(Shanghai) M: Other Areas	I: Malaysia indicates safe	ty critical cor	nponer

Telle ohne Parts No. werden nicht geliefert.							
Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- mark	
D124 D125,126 D125,126 D127,128 D129			UDZ3.9B HSS104A 1SS133 MA111 MA111	ZENER DIODE DIODE DIODE DIODE DIODE DIODE	YMI YMI	6	
D130 D201 D201 D201 D203			MA111 DA204U MA143A 1SS302 HZS8.2N(B2)	DIODE DIODE DIODE DIODE ZENER DIODE			
D203 D204 D204 D209 D209			MTZJ8.2(B) HZS5.1N(B2) MTZJ5.1(B) HZS3.3N(B2) MTZJ3.3(B)	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE			
D211 D213 D601 D602-605 D602-605			MA111 MA111 S1ZB20(4101) HSS104A 1SS133	DIODE DIODE DIODE DIODE DIODE	ET		
D608 D608 D608 IC101 IC101		*	HSS104A RB721Q 1SS133 STK412-010A STK412-010A	DIODE DIODE DIODE HYBRID IC HYBRID IC	KP YMIXET KP ETMXIY KP	5 5	
IC101 IC102 IC102 IC102 IC103		* * * * *	STK412-020A STK413-010A STK413-010A STK413-020A KIA7812API	HYBRID IC HYBRID IC HYBRID IC HYBRID IC ANALOGUE IC	ETMXIY KP	6 5 5 6	
IC104 IC105 IC105 IC106 IC107,108		*	KIA7912PI NJM4580ED NJM4580ED NJU7313AM NJM4565M	ANALOGUE IC ANALOGUE IC ANALOGUE IC ANALOGUE IC ANALOGUE IC	ETMXIY	6 5	
IC109 IC110-112 IC113 IC114 IC201		*	NJU7313AM NJM4565M STK442-090 STK443-090 LA1837	ANALOGUE IC ANALOGUE IC HYBRID IC HYBRID IC ANALOGUE IC	KP KP KPET	4 4	
IC201 IC202 IC601 IC602 Q1 ,2		*	LA1838 LC72131 XC62FP5102P BA05T 2SC1740S(Q,R)	ANALOGUE IC MOS-IC ANALOGUE IC ANALOGUE IC TRANSISTOR	MXIY KP YMIXET		
Q1 ,2 Q5 ,6 Q7 ,8 Q7 ,8 Q11 ,12			2SC2785(F,E) 2SD2351 2SC1740S(Q,R) 2SC2785(F,E) 2SD2351	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR			
Q13 ,14 Q13 ,14 Q16 Q17 Q51 -53			2SC1740S(Q,R) 2SC2785(F,E) 2SD2351 2SC2878(B) 2SA1576A(R,S)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR			
L : Scandinavia Y : PX(Far East Y : AAFES(Euro	,Hawaii)	T:	USA P: Canada England E: Europe Australia Q: Russia	R: Mexico C: China I: Malaysia G: Germany V: China(Shanghai) H: Korea M: Other Areas ⚠ indicates saf	ety critical con	nponen	

®

* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

A

			erden nicht geliefert.	o. ne sont pas fourni	S.			Ø
Ref. No	Add- ress	New Parts	Parts No.	De	escription		Desti- nation	Re- marks
C34 C35 C41 C42 C43 ,44			CK73FB1H472K CK73FF1C105Z CC73FCH1H220J CC73FCH1H270J CK73FB1H102K	CHIP C CHIP C CHIP C CHIP C CHIP C	4700PF 1.0UF 22PF 27PF 1000PF	K Z J J K		
C45 C46 C54 ,55 C56 C57			CK73FB1H103K CC73FCH1H220J CC73FCH1H220J CK73FB1H102K CK73FF1C105Z	CHIP C CHIP C CHIP C CHIP C CHIP C	0.010UF 22PF 22PF 1000PF 1.0UF	K J J K Z		
C58 ,59 C103,104 C105,106 C107,108 C109			CK73FB1H103K CK73FF1C105Z CK73FB1H182K CK73FB1H222K CK73FB1H103K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.010UF 1.0UF 1800PF 2200PF 0.010UF	K Z K K K		
C110 C121,122 C125 C126 C141			CC73FCH1H101J CC73FCH1H220J CK73FB1H103K CC73FCH1H101J CC73FCH1H101J	CHIP C CHIP C CHIP C CHIP C CHIP C	100PF 22PF 0.010UF 100PF 100PF	J K J		
C151,152 C153,154 C155,156 C157-160 C161,162			CK73FF1C225Z CC73FCH1H101J CK73FF1C105Z CK73FF1C225Z CK73FB1H822K	CHIP C CHIP C CHIP C CHIP C CHIP C	2.2UF 100PF 1.0UF 2.2UF 8200PF	Z J Z Z K		
C163,164 C165,166 C167,168 C169,170 C177-182			CK73FB1H153K CK73FB1C334K CK73FF1C225Z CK73FB1H222K CK73FF1C225Z	CHIP C CHIP C CHIP C CHIP C CHIP C	0.015UF 0.33UF 2.2UF 2200PF 2.2UF	K K Z K Z		
C183 C184 C185,186 C187,188 C203,204			CK73FF1C105Z CC73FCH1H221J CK73FB1E104K CK73FB1H102K CK73FF1C105Z	CHIP C CHIP C CHIP C CHIP C CHIP C	1.0UF 220PF 0.10UF 1000PF 1.0UF	Z J K K Z		
C205,206 C207,208 C209 C210 C251-256			CK73FB1H182K CK73FB1H222K CK73FB1H103K CC73FCH1H101J CC73FCH1H221J	CHIP C CHIP C CHIP C CHIP C CHIP C	1800PF 2200PF 0.010UF 100PF 220PF	K K K J		
C303,304 C305 C306 C307 C308			CK73FF1C105Z CK73FB1H182K CK73FB1H682K CK73FB1H222K CK73FB1H822K	CHIP C CHIP C CHIP C CHIP C CHIP C	1.0UF 1800PF 6800PF 2200PF 8200PF	Z K K K K		
C309 C310 C401-403 C411-414 C415-418			CK73FB1H103K CC73FCH1H101J CK73FB1H103K CC73FCH1H220J CC73FCH1H101J	CHIP C CHIP C CHIP C CHIP C CHIP C	0.010UF 100PF 0.010UF 22PF 100PF	K J K		
C419 C450 C451 C452 C453,454			CC73FCH1H100D CK73FB1H103K CK73FB1E104K CE04LW1C222M CK73FB1E104K	CHIP C CHIP C CHIP C ELECTRO CHIP C	10PF 0.010UF 0.10UF 2200UF 0.10UF	D K K 16WV K		

L : Scandinavia	K: USA	P: Canada	R: Mexico	C : China	I : Malaysia

Y: PX(Far East, Hawaii) T: England E: Europe G: Germany V: China(Shanghai) M: Other Areas indicates safety critical components. Y: AAFES(Europe) X : Australia Q : Russia H: Korea

* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis. Teile ohne **Parts No.** werden nicht geliefert.

Y: PX(Far East, Hawaii) T: England

X : Australia

Y: AAFES(Europe)

E: Europe

Q: Russia

G: Germany

H: Korea

Ref. No	Add- ress	New Parts	Parts No.	De	escription			Desti- nation	Re- marks
C455 C456,457 C458 C459,460 C461			CE04LW1A101M CK73FB1E104K C92-0047-05 CK73FB1E104K CE04LW1E470M	ELECTRO CHIP C CHIP-ELE CHIP C ELECTRO	100UF 0.10UF 47UF 0.10UF 47UF		10WV K 6.3WV K 25WV		
C501-504 C505 C506 C507 C508			CK73FB1E104K CK73FB1H102K CC73FCH1H471J CK73FB1H103K CE04LW1H2R2M	CHIP C CHIP C CHIP C CHIP C ELECTRO	0.10UF 1000PF 470PF 0.010UF 2.2UF		K K J K 50WV		
C509 C510,511 C601 C602 C603			CE04LW1E470M CK73FB1H103K CC73FCH1H470J CE04LW1E470M CC73FCH1H470J	ELECTRO CHIP C CHIP C ELECTRO CHIP C	47UF 0.010UF 47PF 47UF 47PF		25WV K J 25WV J		
C604 C607 C608 C609,610 C621,622			CE04LW1E470M CC73FCH1H470J CE04LW1E470M CC73FCH1H470J CK73FB1E104K	ELECTRO CHIP C ELECTRO CHIP C CHIP C	47UF 47PF 47UF 47PF 0.10UF		25WV J 25WV J K		
C751,752 C753			CC73FCH1H221J CK73FB1H103K	CHIP C CHIP C	220PF 0.010UF		J K		
CN1 CN2 CN5 CN5 J1		* *	E40-8485-05 E40-8484-05 E40-4248-05 E40-8358-05 E63-1080-05	FLAT CABLE CON FLAT CABLE CON PIN ASSY PIN ASSY PIN JACK					
J1 J2 J2 J3 J61		* * * *	E63-1140-05 E63-1139-05 E63-1139-05 E63-1138-05 E63-1141-05	PIN JACK PIN JACK PIN JACK PIN JACK PIN JACK				ETMXIY KP	6 5 45
J75			E11-0293-05	MINIATURE PHON	IE JACK(2P))			
E1 ,2			J11-0809-05	WIRE CLAMPER					
L31 ,32 L41 X1		* * *	L92-0511-05 L92-0510-05 L77-2296-05	CHIP FERRITE CHIP FERRITE CRYSTAL RESON	ATOR(12.28	88MH	Z)		
CP41-44 CP51,52 R1 ,2 R3 ,4 R5 ,6			R90-0728-05 R90-0714-05 RK73FB2A562J RK73FB2A101J RK73FB2A471J	MULTI-COMP MULTI-COMP CHIP R CHIP R CHIP R	180 X4 10K X4 5.6K 100 470	J J J	1/10W 1/10W 1/10W		
R7 -10 R11 ,12 R20 R21 R31 ,32		*	RK73FB2A472J RK73FB2A471J R92-1946-05 RK73FB2A221J RK73FB2A820J	CHIP R CHIP R METAL GLAZE CHIP R CHIP R	4.7K 470 4.7 220 82	J J J	1/10W 1/10W 1/4W 1/10W 1/10W		
R33 R34 R41 ,42 R43 -45 R54			RK73FB2A471J RD14NB2E4R7J RK73FB2A105J RK73FB2A221J RK73FB2A912J	CHIP R RD CHIP R CHIP R CHIP R	470 4.7 1.0M 220 9.1K	J J J J	1/10W 1/4W 1/10W 1/10W 1/10W		

V: China(Shanghai)

Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.



Ø

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.



KRF-V4530D/V5030D/V6030D/VR-405/406/414 PARTS LIST

Ref. No	Add- ress	New Parts	Parts No.		escription			Desti- nation	Re
R465 R501-503 R505 R514 R515			RK73FB2A102J RK73FB2A221J RK73FB2A103J RK73FB2A101J RK73FB2A221J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.0K 220 10K 100 220	J	1/10W 1/10W 1/10W 1/10W 1/10W		
R516 R517 R518 R519 R520,521			RK73FB2A103J RK73FB2A221J RK73FB2A472J RK73FB2A221J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	10K 220 4.7K 220 10K	J	1/10W 1/10W 1/10W 1/10W 1/10W		
R522,523 R524 R527 R601 R603			RK73FB2A472J RK73FB2A333J RK73FB2A103J RK73FB2A820J RK73FB2A820J	CHIP R CHIP R CHIP R CHIP R CHIP R	4.7K 33K 10K 82 82]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
R607 R609 R610 R611 R612			RK73FB2A820J RK73FB2A104J RK73FB2A680J RK73FB2A104J RK73FB2A680J	CHIP R CHIP R CHIP R CHIP R CHIP R	82 100K 68 100K 68]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
R613 R631,632 R633,634		*	RK73FB2A1R0J RK73FB2A681J R92-1954-05	CHIP R CHIP R METAL GLAZE	1 680 100	J	1/10W 1/10W 1/10W		
D1 D1 D1 D2 D2			DAN202U MA142WK 1SS301 DAP202U MA142WA	DIODE DIODE DIODE DIODE DIODE					
D2 D3 D3 D3 D6			1SS300 DAN202U MA142WK 1SS301 MA111	DIODE DIODE DIODE DIODE DIODE					
D41 D42 ,43 D44 D51 ,52 D61 ,62			S1ZB20(4072) UDZ5.6B UDZ3.9B MA111 UDZ5.6B	DIODE ZENER DIODE ZENER DIODE DIODE ZENER DIODE					
D75 ,76 D151,152 IC1 IC2 IC4		*	MA111 UDZ7.5B NJM4565MD AK4527-VQ TC7WU04FU	DIODE ZENER DIODE IC(OP AMP X2) MOS-IC MOS-IC					
IC5 IC6 IC11 IC12 IC13		*	AK4110-VF TC7WH123FU NJM4565MD NJU7311AM NJM4565MD	MOS-IC MOS-IC IC(OP AMP X2) MOS-IC IC(OP AMP X2)					
IC14 IC15 IC21 IC31 IC41		*	NJU7311AM M62446FP NJM4565MD NJM4565MD TC74HC07AF	MOS-IC ANALOGUE IC IC(OP AMP X2) IC(OP AMP X2) MOS-IC					
IC42			TC74HCT7007AF	MOS-IC					

			escription			nation	marks
	RK73FB2A221J RK73FB2A101J RK73FB2A104J RK73FB2A103J RK73FB2A221J	CHIP R CHIP R CHIP R CHIP R CHIP R	220 100 100K 10K 220	J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A222J RK73FB2A104J RK73FB2A222J RK73FB2A103J RK73FB2A472J	CHIP R CHIP R CHIP R CHIP R CHIP R	2.2K 100K 2.2K 10K 4.7K	J J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A221J RK73FB2A103J RK73FB2A101J RK73FB2A242J RK73FB2A100J	CHIP R CHIP R CHIP R CHIP R CHIP R	220 10K 100 2.4K 10	J J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A102J RK73FB2A101J RK73FB2A751J RK73FB2A272J RK73FB2A1R0J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.0K 100 750 2.7K 1	J J J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A471J RK73FB2A473J RK73FB2A102J RK73FB2A104J RK73FB2A472J	CHIP R CHIP R CHIP R CHIP R CHIP R	470 47K 1.0K 100K 4.7K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A272J RK73FB2A562J RK73FB2A221J RK73FB2A472J RK73FB2A562J	CHIP R CHIP R CHIP R CHIP R CHIP R	2.7K 5.6K 220 4.7K 5.6K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A153J RK73FB2A223J RK73FB2A103J RK73FB2A223J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	15K 22K 10K 22K 10K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A223J RK73FB2A222J RK73FB2A103J RK73FB2A104J RK73FB2A222J	CHIP R CHIP R CHIP R CHIP R CHIP R	22K 2.2K 10K 100K 2.2K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A123J RK73FB2A103J RK73FB2A472J RK73FB2A221J RK73FB2A471J	CHIP R CHIP R CHIP R CHIP R CHIP R	12K 10K 4.7K 220 470	J J J	1/10W 1/10W 1/10W 1/10W 1/10W		
	RK73FB2A473J RK73FB2A221J RK73FB2A221J RK73FB2A1R0J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	47K 220 220 1 10K	J	1/10W 1/10W 1/10W 1/10W 1/10W		
*	R92-1945-05 R92-1946-05 RK73FB2A221J RK73FB2A473J RK73FB2A472J	METAL GLAZE METAL GLAZE CHIP R CHIP R CHIP R	1 4.7 220 47K 4.7K	J J J	1/4W 1/4W 1/10W 1/10W 1/10W		
		RK73FB2A221J RK73FB2A222J RK73FB2A104J RK73FB2A103J RK73FB2A103J RK73FB2A103J RK73FB2A103J RK73FB2A103J RK73FB2A100J	RK73FB2A221J CHIP R RK73FB2A104J CHIP R RK73FB2A104J CHIP R RK73FB2A103J CHIP R RK73FB2A173J CHIP R RK73FB2A473J CHIP R RK73FB2A473J CHIP R RK73FB2A103J CHIP R RK73FB2A103J CHIP R RK73FB2A103J CHIP R RK73FB2A2103J CHIP R RK73FB2A213J CHIP R RK73FB2A221J CHIP R RK73FB2A223J CHIP R RK73FB2A103J CHIP R RK73FB2A103J CHIP R RK73FB2A103J CHIP R RK73FB2A103J CHIP R RK73FB2A223J CHIP R RK73FB2A103J CHIP R	RK73FB2A221J CHIP R 2.2K RK73FB2A104J CHIP R 100K RK73FB2A104J CHIP R 100K RK73FB2A103J CHIP R 2.2K RK73FB2A103J CHIP R 10K RK73FB2A101J CHIP R 100 RK73FB2A101J CHIP R 100 RK73FB2A100J CHIP R 10 RK73FB2A100J CHIP R 10 RK73FB2A100J CHIP R 10 RK73FB2A101J CHIP R 100 RK73FB2A102J CHIP R 2.7K RK73FB2A102J CHIP R 1.0K RK73FB2A222J CHIP R 2.20 RK73FB2A222J CHIP R 2.2C RK73FB2A222J CHIP R 2.2C RK73FB2A103J CHIP R 1.0K RK73FB2A103J CHIP	RK73FB2A221J CHIP R 220 J RK73FB2A222J CHIP R 100K J RK73FB2A04D4J CHIP R 2.2K J RK73FB2A222J CHIP R 2.2K J RK73FB2A222J CHIP R 2.2K J RK73FB2A4703J CHIP R 10K J RK73FB2A472J CHIP R 10K J RK73FB2A103J CHIP R 10K J RK73FB2A101J CHIP R 100 J RK73FB2A101J CHIP R 10 J RK73FB2A102J CHIP R 10 J RK73FB2A101J CHIP R 10 J RK73FB2A751J CHIP R 750 J RK73FB2A751J CHIP R 750 J RK73FB2A471J CHIP R 1 J RK73FB2A470J CHIP R 1 LOK J RK73FB2A470J CHIP R 470 J RK73FB2A470J CHIP R 1 LOK J RK73FB2A470J CHIP R 1 LOK J RK73FB2A210J CHIP R 1 LOK J RK73FB2A210J CHIP R 1 LOK J RK73FB2A221J CHIP R 1 LOK J RK73FB2A221J CHIP R 1 LOK J RK73FB2A221J CHIP R 2.7K J RK73FB2A221J CHIP R 2.0 J RK73FB2A222J CHIP R 2.0 J RK73FB2A223J CHIP R 2.0 J RK73FB2A223J CHIP R 4.7K J RK73FB2A223J CHIP R 2.2K J RK73FB2A3 CHIP R 10K J RK73FB2A3 CHIP R 10K J RK73FB2A3 CHIP R 10K J RK73FB2A3 CHIP R 2.2 C J RK73FB2A3 CHIP R 2.	RK73FB2A221J CHIP R 220 J 1/10W RK73FB2A222J CHIP R 2.2K J 1/10W RK73FB2A104J CHIP R 100K J 1/10W RK73FB2A103J CHIP R 2.2K J 1/10W RK73FB2A472J CHIP R 10K J 1/10W RK73FB2A472J CHIP R 10K J 1/10W RK73FB2A472J CHIP R 10K J 1/10W RK73FB2A473J CHIP R 10K J 1/10W RK73FB2A103J CHIP R 10K J 1/10W RK73FB2A103J CHIP R 10K J 1/10W RK73FB2A210J CHIP R 10W J 1/10W RK73FB2A242J CHIP R 10W J 1/10W RK73FB2A242J CHIP R 10W J 1/10W RK73FB2A242J CHIP R 10W J 1/10W RK73FB2A100J CHIP R 10W J 1/10W RK73FB2A101J CHIP R 10W J 1/10W RK73FB2A272J CHIP R 750 J 1/10W RK73FB2A272J CHIP R 2.7K J 1/10W RK73FB2A272J CHIP R 2.7K J 1/10W RK73FB2A470J CHIP R 10W J 1/10W RK73FB2A470J CHIP R 2.7K J 1/10W RK73FB2A470J CHIP R 2.7K J 1/10W RK73FB2A470J CHIP R 2.7W J 1/10W RK73FB2A400J CHIP R 2.7W J 1/10W RK73FB2A400J CHIP R 2.7W J 1/10W RK73FB2A400J CHIP R 2.7W J 1/10W RK73FB2A223J CHIP R 2.7W J 1/10W RK73FB2A223J CHIP R 2.7W J 1/10W RK73FB2A203J CHIP R 2.7W J 1/10W RK73FB2A103J CHIP R 10W J 1/10W RK73FB2A400J CHIP R 2.7W J 1/10W RK73FB2A470J CHIP R 2.7W J	RK73FB2A221J CHIP R 220 J 1/10W RK73FB2A222J CHIP R 2.2K J 1/10W RK73FB2A104J CHIP R 2.2K J 1/10W RK73FB2A103J CHIP R 2.2K J 1/10W RK73FB2A103J CHIP R 2.2K J 1/10W RK73FB2A103J CHIP R 10K J 1/10W RK73FB2A103J CHIP R 10K J 1/10W RK73FB2A103J CHIP R 10K J 1/10W RK73FB2A101J CHIP R 100 J 1/10W RK73FB2A100J CHIP R 10W J 1/10W RK73FB2A20J CHIP R 2.7K J 1/10W RK73FB2A20J CHIP R 2.7K J 1/10W RK73FB2A20J CHIP R 2.7K J 1/10W RK73FB2A20J CHIP R 2.0W J 1/10W RK73FB2A20J CHIP R 15K J 1/10W RK73FB2A20J CHIP R 15K J 1/10W RK73FB2A20J CHIP R 10K J 1/10W RK73FB2A10J CHIP R 10W J 1/10W RK73FB2A10J CHIP R 10

L: Scandinavia Y: PX(Far East, Hawaii) T: England E: Europe Y: AAFES(Europe)

K:USA

X : Australia Q : Russia

P : Canada

R: Mexico G: Germany H: Korea

C: China V: China(Shanghai)

I : Malaysia

M: Other Areas ▲ indicates safety critical components.

Y: PX(Far East, Hawaii) T: England E: Europe G: Germany V: China(Shanghai) Y: AAFES(Europe)

X: Australia Q: Russia H: Korea

Parts without **Parts No.** are not supplied.

Y: PX(Far East, Hawaii) T: England

Y: AAFES(Europe)

E: Europe

X: Australia Q: Russia

G: Germany

H: Korea

V: China(Shanghai)

M: Other Areas ⚠ indicates safety critical components.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis



	Teile ohne I	Parts No	o. we	erden nicht geliefert.					•
	Ref. No	Add- ress	New Parts	Parts No.	D	escription		Desti- nation	Re- marks
Λ	IC45 IC46 IC47 IC51 IC51		* * * *	TA48M05F TA48M033F TA48M025F CS493253-CLR CS493263-CLR	ANALOGUE IC ANALOGUE IC ANALOGUE IC MOS-IC MOS-IC				
<u>^</u>	IC61 Q1 Q1 Q15 Q15		*	NJM2279M DTC124EUA UN5212 2SD1664(Q,R) 2SD1963(R,S)-G	ANALOGUE IC DIGITAL TRANSIS DIGITAL TRANSIS TRANSISTOR TRANSISTOR	STOR STOR			
<u>^</u>	Q16 Q16 Q41 Q41 Q42		*	2SB1132(Q,R) 2SB1308(Q,R)-G 2SC4081(R,S) 2SD1819A(Q,R) 2SA1576A(R,S)	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR				
<u>^</u>	Q42 Q61 Q61 Q62 Q62		*	2SB1218A(Q,R) 2SD1664(Q,R) 2SD1963(R,S)-G 2SB1132(Q,R) 2SB1308(Q,R)-G	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR				
	A1		*	W02-2716-05	OPTIC RECEIVING				
				DISP	LAY (X14-71	20-10)			
	D1 D3 -5		*	B30-2567-05 B30-2545-05	LED(RED(80) HI-B LED(RED3(160))	iR)			
	C1 C1 C2 C3 C4 ,5			CE04RW0J331M CE04RW1A101M CK73FB1H103K CE04RW1H010M CE04RW1C100M	ELECTRO ELECTRO CHIP C ELECTRO ELECTRO	330UF 100UF 0.010UF 1.0UF 10UF	6.3WV 10WV K 50WV 16WV	KP ETMXIY	
	C6 C7 C9 C10 -19 C20 ,21		*	CE04RW0J100M CK73FB1H103K CC73FCH1H470J CK73FB1H103K CK73FB1C104K	ELECTRO CHIP C CHIP C CHIP C CHIP C	10UF 0.010UF 47PF 0.010UF 0.10UF	6.3WV K J K K		
	C22 C23 C24 C25 C26 ,27			CK73FF1C105Z CE04RW0J470M CE04RW0J470M CK73FB1H103K CC73FCH1H270J	CHIP C ELECTRO ELECTRO CHIP C CHIP C	1.0UF 47UF 47UF 0.010UF 27PF	Z 6.3WV 6.3WV K J	ET ET ET	
	C28 C29 C30 C31 C32		*	CC73FCH1H561J CC73FCH1H271J CE04RW1V2R2M CC73FCH1H101J CE04RW0J220M	CHIP C CHIP C ELECTRO CHIP C ELECTRO	560PF 270PF 2.2UF 100PF 22UF	J J 35WV J 6.3WV	ET ET ET ET	
	C33 -35 C36 ,37 C38 C39 C40		*	CC73FCH1H101J CC73FCH1H470J CE04RW1H330M CK73FB1H103K C90-1826-05	CHIP C CHIP C ELECTRO CHIP C BACKUP-C	100PF 47PF 33UF 0.010UF 0.047F	J J 50WV K 5.5WV	YMIXET	
	C41 C42 C43 ,44 C45 ,46 C47			CK73FB1H103K CK73FB1H103K CC73FCH1H101J CC73FCH1H470J CC73FCH1H101J	CHIP C CHIP C CHIP C CHIP C CHIP C	0.010UF 0.010UF 100PF 47PF 100PF	K K J J	MXI MXIY	
	L : Scandinavi			USA P: Canada		China China(Shanghai)	I : Malaysia	1	

* New Parts Parts without **Parts No.** are not supplied. Les articles non mentionnes dans le **Parts No**. ne sont pas fournis. Teile ohne **Parts No**. werden nicht geliefert.

Y: PX(Far East, Hawaii)

Y: AAFES(Europe)

T: England

X : Australia

E: Europe

Q: Russia

G: Germany

H: Korea

@

Ref. No	Add- ress	New Parts	Parts No.	De	escription			Desti- nation	Re- marks
C48 C49 C50 C51 C52		*	CC73FCH1H101J CE04RW0J331M CC73FCH1H101J CE04RW1H2R2M CK73FB1H103K	CHIP C ELECTRO CHIP C ELECTRO CHIP C	100PF 330UF 100PF 2.2UF 0.010UF		J 6.3WV J 50WV K	YMI KP YMI ET	
C53 C54 C55 C56 C57		*	CC73FCH1H101J CE04RW1H4R7M CC73FCH1H470J CC73FCH1H220J CC73FCH1H221J	CHIP C ELECTRO CHIP C CHIP C CHIP C	100PF 4.7UF 47PF 22PF 220PF		J 50WV J J J		
C58 C59 C106,107			CC73FCH1H470J CK73FF1C105Z CC73FCH1H101J	CHIP C CHIP C CHIP C	47PF 1.0UF 100PF		J Z J		
CN1 CN2 CN3 CN5 J1		*	E40-8510-05 E40-8504-05 E40-3247-05 E40-3261-05 E11-0272-05	FLAT CABLE CONN FLAT CABLE CONN PIN ASSY PIN ASSY PHONE JACK					
E5			J11-0808-05	WIRE CLAMPER					
X1 X2		*	L78-0714-05 L77-2002-05	RESONATOR CRYSTAL RESONA	(8MHZ) ATOR(4.332	MHZ)	ı	ET	
CP1 CP2 ,3 CP501 CP502 R4			R90-0855-05 R90-0482-05 R90-0855-05 R90-0850-05 RK73FB2A102J	MULTI-COMP MULTI-COMP MULTI-COMP MULTI-COMP CHIP R	100KX5 100KX4 100KX5 100KX3 1.0K]]]	1/6W 1/6W 1/10W		
R5 R7 R8 R11 R12			RK73FB2A103J RK73FB2A104J RK73FB2A102J RK73FB2A223J RK73FB2A331J	CHIP R CHIP R CHIP R CHIP R CHIP R	10K 100K 1.0K 22K 330]]]	1/10W 1/10W 1/10W 1/10W 1/10W	ҮМІ	
R13 ,14 R15 R29 R31 -33 R36 ,37			RK73FB2A104J RK73FB2A331J RK73FB2A122J RK73FB2A221J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K 330 1.2K 220 100K]]]	1/10W 1/10W 1/10W 1/10W 1/10W		
R38 -43 R44 -49 R50 R51 R52 ,53			RK73FB2A103J RK73FB2A101J RK73FB2A272J RK73FB2A102J RK73FB2A272J	CHIP R CHIP R CHIP R CHIP R CHIP R	10K 100 2.7K 1.0K 2.7K]]]	1/10W 1/10W 1/10W 1/10W 1/10W	YMI	
R54 ,55 R57 ,58 R59 -63 R64 R65 ,66			RK73FB2A103J RK73FB2A223J RK73FB2A104J RK73FB2A101J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	10K 22K 100K 100 10K]]]	1/10W 1/10W 1/10W 1/10W 1/10W	YMI	
R67 R69 ,70 R71 ,72 R83 R86			RD14NB2E222J RK73FB2A103J RK73FB2A473J RK73FB2A564J RD14NB2E152J	RD CHIP R CHIP R CHIP R RD	2.2K 10K 47K 560K 1.5K]]]	1/4W 1/10W 1/10W 1/10W 1/4W	YMI	
R98 R107-109			RK73FB2A104J RK73FB2A104J	CHIP R CHIP R	100K 100K	J	1/10W 1/10W		
L : Scandinavia			USA P: Canada	R: Mexico C: C	hina		Malaysia		

V: China(Shanghai)

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis



Ref. No	Add- ress	New Parts		Description				Desti- nation	Re- mark	
R110 R111 R112 R113 R114			RK73FB2A1R0J RK73FB2A101J RK73FB2A473J RK73FB2A101J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	1 100 47K 100 100K	1	1/10W 1/10W 1/10W 1/10W 1/10W	ET ET ET ET		
R118 R119-126 R127-129 R130 R141,142			RK73FB2A104J RK73FB2A101J RK73FB2A104J RK73FB2A102J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K 100 100K 1.0K 100K	J	1/10W 1/10W 1/10W 1/10W 1/10W			
R143 R161,162 R501,502 W503 W505			RK73FB2A101J RK73FB2A104J RK73FB2A104J R92-0679-05 R92-0679-05	CHIP R CHIP R CHIP R CHIP R CHIP R	100 100K 100K 0 OHM 0 OHM	J	1/10W 1/10W 1/10W	YMI		
W509 W514			R92-0679-05 R92-0679-05	CHIP R CHIP R	0 OHM 0 OHM					
S4 -18 S19			\$70-0031-05 \$68-0107-05	TACT SWITCH PUSH SWITCH				YMIXET		
S1 S2		*	T99-0602-05 T99-0630-05	ROTARY ENCODE ROTARY ENCODE						
D7 D7 D8 ,9 D11 ,12 D13			HZS6.2N(B2) MTZJ6.2(B) RB721Q MA111 HSS104A	ZENER DIODE ZENER DIODE DIODE DIODE DIODE DIODE				KP		
D13 D15 ,16 D17 -22 D17 -22 D24			1SS133 MA111 HSS104A 1SS133 HSS104A	DIODE DIODE DIODE DIODE DIODE				KP ETX		
D24 D27 D27 D28 D28			1SS133 HSS104A 1SS133 HSS104A 1SS133	DIODE DIODE DIODE DIODE DIODE				ETX KP KP ETMXIY ETMXIY	6	
D29 D29 D30 D30 D33			HSS104A 1SS133 HSS104A 1SS133 HSS104A	DIODE DIODE DIODE DIODE DIODE				X X ET ET		
D33 D35 ,36 ED1 IC1 IC2		* *	1SS133 MA111 SVA-11MS22 MN101C35DRA S-80840ANY	DIODE DIODE FLUORESCENT IN MI-COM IC ANALOGUE IC	NDICATOR '	TUBE		YMI		
IC3 IC4 IC5 IC6 Q1		*	TA78057F BU1923F S-80840ANY XC62FP5102P 2SC4081(R,S)	ANALOGUE IC ANALOGUE IC ANALOGUE IC ANALOGUE IC TRANSISTOR				KPXET ET YMI YMI		
Q2 Q3 -5			2SA1576A(R,S) 2SC4081(R,S)	TRANSISTOR TRANSISTOR						

H: Korea

G: Germany

V: China(Shanghai)

M: Other Areas ▲ indicates safety critical components.

* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis. Telle ohne **Parts No.** werden nicht geliefert.



Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
Q6 Q9 -11 Q12 ,13 Q14 Q14			UN5219 UN5219 2SA1576A(R,S) DTA124EUA UN5112	DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR		
A1			W02-2625-05	OPTIC RECEIVING MODULE		

G: Germany M: Other Areas ⚠ indicates safety critical components Y: AAFES(Europe) X : Australia O : Russia H: Korea

V : China(Shanghai)

HOW TO READ THE PARTS LIST

Y: PX(Far East, Hawaii) T: England E: Europe

DOWN OR READ THE PARTY SLID DESIGNATION OF Sale country and model.

Alphabets mean the country, Numerals do model.

Example: X nears KRF-V5300D, Sand KRF-V5030D-S for Australia market.

5 does KRF-V430D, KRF-5030D, KRF-V5030DE KRF-V5030D-S and VR-405.

ABBREVIATION OF MODEL AND MASS PRODUCTION'S DESTINATIONS

MODEL	CNT	Australia	Canada	China	England	Europe	Germany	Korea	Malaysia
WODEL	ABB.	X	P	С	Т	E	G	н	1
KRF-V4530D	5	-	-	-	-	E4	-	-	-
KRF-V5030D	5	-	-	-	T5	E1	-	-	-
KRF-V5030DE	5	-	-	-	-	E2	-	-	-
KRF-V5030D-S	5	X5	-	-	-	E3	-	-	15
KRF-V6030D	6	-	-	-	-	E6	-	-	-
KRF-V6030DE	6	-	-	-	-	E7	-	-	-
KRF-V6030D-S	6	X6	-	-	-	-	-	-	16
VR-405	5	-	P5	-	-	-	-	-	-
VR-406	6	-	P6		-	-	-	-	-
VR-414	4	-	P4	-	-	-	ı	-	-
MODE	CNT	Mexico	PX/AAFES	Russia	Scandinavia	Shanghai	USA	Other area	Other area(M
MODEL	ABB.	R	Y	Q	L	V	K	М	M2
KRF-V4530D	5	-	-	-	-	-	-	-	-
				-		_	_	-	-
KRF-V5030D	5	-	Y5	-	- 1	-			
KRF-V5030D KRF-V5030DE	5	-	Y5 -	-	-	-	-	-	-
								- M5	-
KRF-V5030DE	5	-	-	-	-	-	-		
KRF-V5030DE KRF-V5030D-S	5	-	-	-	-	-	-	M5	-
KRF-V5030DE KRF-V5030D-S KRF-V6030D	5 5		-		-	- - -	-	M5 -	-
KRF-V5030DE KRF-V5030D-S KRF-V6030D KRF-V6030DE	5 5 6 6	- - -		- - -	- - -	- - -	- - -	M5 -	
KRF-V5030DE KRF-V5030D-S KRF-V6030D KRF-V6030DE KRF-V6030D-S	5 5 6 6	- - - -	-	- - - -		- - - -	- - - -	M5 - - M6	- - -

Y: AAFES(Europe)

X: Australia Q: Russia

Y: PX(Far East, Hawaii) T: England E: Europe

SPECIFICATIONS

For U.S.A and Canada

AUDIO section (VR-407/406)

Rated power output during STEREO operation

100 watts per channel minimum RMS, both channels driven, at $\,8\,\Omega$ from 20 Hz (VR-407), 40Hz (VR-406) to 20 kHz with no more than 0.7% total harmonic distortion. (FTC)

Effective power output during SURROUND operation
FRONT (20-20kHz/VR-407, 40-20kHz/VR-406, 0.7% T.H.D. at 8 Ω
one channel driven) 100 W + 100 W
CENTER (20-20kHz/VR-407, 40-20kHz/VR-406, 0.7% T.H.D. at 8
Ω one channel driven)
SURROUND (20-20kHz/VR-407, 40-20kHz/VR-406, 0.7% T.H.D.
at 8 Ω one channel driven) 100 W + 100 W
Total harmonic distortion 0.055% (1 kHz, 50W, 8 Ω)
Frequency response
CD
Signal to noise ratio (IHF'66)
PHONO (MM)75 dB
CD
Input sensitivity / impedance
PHONO (MM)
CD
MONITOR IN (VR-406:VIDEO2/MONITOR) 200 mV / 47 k Ω
Output level / impedance
TAPE REC 200 mV / 1 k Ω
MONITOR OUT (VR-406:VIDEO2/MONITOR) 200 mV / 1 k Ω
PRE OUT (SUBWOOFER)
Tone control
BASS±10 dB (at 100 Hz)
TREBLE±10 dB (at 10 kHz)

AUDIO section (VR-405/414)

Rated power output during STEREO operation

80 watts (VR-405), 50watts (VR-414) per channel minimum RMS, both channels driven, at $\,8\,\Omega$ from 40 Hz to 20 kHz with no more than 0.7% total harmonic distortion. (FTC)

Effective power output during SURROUND operation FRONT (40-20kHz, 0.7% T.H.D. at 8 Ω one channel driven) CENTER (40-20kHz, 0.7% T.H.D. at 8 Ω one channel driven)80 W (VR-405), 50 W (VR-414) SURROUND (40-20kHz, 0.7% T.H.D. at 8 Ω one channel driven) 80 W + 80 W (VR-405), 50 W + 50 W (VR-414) Total harmonic distortion 0.055% (1 kHz, 40W, 8 Ω) Frequency response Signal to noise ratio (IHF'66) Input sensitivity / impedance MONITOR IN (VIDEO2/MONITOR) 200 mV / 47 k Ω Output level / impedance MONITOR OUT (VIDEO2/MONITOR) 200 mV / 1 k Ω Tone control BASS ±10 dB (at 100 Hz)

TREBLE ±10 dB (at 10 kHz)

DIGITAL AUDIO section

Sampling frequency	Ηz
Optical	
VIDEO section	
VIDEO inputs / outputs	_
VIDEO (composite)	Ω
(luminance signal) 1 Vp-p / 75	
(chrominance signal)	Ω
FM tuner section	
Tuning frequency range	
	3)
STEREO	Bf
Total harmonic distortion (1 kHz)	
MONO	
Signal to noise ratio (1 kHz, 75 kHz DEV.)	•••
MONO	
Stereo separation (1 kHz)	
Selectivity (±400 kHz)70 c	dΒ
Frequency response	iΒ
AM tuner section	
Tuning frequency range	
10 kHz step	
Signal to noise ratio (30% mod. 1 mV input)	
GENERAL	
Power consumption (VR-414)	
(VR-405)	
AC outlet	
SWITCHED (total 150 W, 1.25 A max Dimensions	
H : 143 mm (5-5/8	
D: 400 mm (15-3/4	
Weight (Net)	b)

Notes

^{1.} KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

^{2.} The full performance may not be exhibited in an extremely cold location (under a water-freezing temperature).

KRF-V4530D/V5030D/V6030D/VR-405/406/414 **SPECIFICATIONS**

For other countries

r or other countries
AUDIO section (KRF-V7030D/V6030D)
Effective power output during STEREO operation
1kHz,10% T.H.D.,at 8 Ω140 W + 140 W Rated power output during STEREO operation
100 watts per channel minimum RMS, both channels driven, at 8 Ω from 40 Hz (KRF-V6030D) , 20Hz (KRF-V7030D) to 20 kHz with no more than 0.7% total harmonic distortion.(FTC)
Effective power output during SURROUND operation
FRONT (1kHz, 10% T.H.D. at 8 Ω one channel driven)140 W + 140 W
CENTER (1kHz, 10% T.H.D. at 8 Ω one channel driven)
SURROUND (1kHz, 10% T.H.D. at 8 Ω one channel driven) 140 W + 140 W
Total harmonic distortion 0.055% (1 kHz, 50W, 8 Ω)
Frequency response CD
Signal to noise ratio (IHF'66) PHONO (MM)
CD91 dB
Input sensitivity / impedance PHONO (MM)
CD
MONITOR IN (KRF-V6030D:VIDEO2/MONITOR)
TAPE REC
MONITOR OUT (KRF-V6030D:VIDEO2/MONITOR)
BASS (For Australia and U.S-Military)±10 dB (at 100 Hz)
BASS (Other countries)±10 dB (at 60 Hz) TREBLE±10 dB (at 10 kHz)
AUDIO section (KRF-V5030D)
Effective power output during STEREO operation (1 kHz, 10%, 8Ω)
80 watts channel minimum RMS, both channels driven, at 8 Ω from 40 Hz to 20 kHz with no more than 0.7% total harmonic distortion. (FTC)
Effective power output during SURROUND operation
FRONT (1kHz, 10% T.H.D. at 8 Ω one channel driven) 110 W + 110 W
CENTER (1kHz, 10% T.H.D. at 8 Ω one channel driven)
SURROUND (1kHz, 10% T.H.D. at 8 Ω one channel driven)
Total harmonic distortion
Frequency response CD
Signal to noise ratio (IHF'66)
PHONO (MM)
Input sensitivity / impedance
PHONO (MM)
CD

MONITOR IN (VIDEO2/MONITOR) 200 mV / 47 k Ω Output level / impedance
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
BASS (For Australia and U.S-Military)±10 dB (at 100 Hz) BASS (Other countries)±10 dB (at 60 Hz) TREBLE±10 dB (at 10 kHz)
DIGITAL AUDIO section
Sampling frequency
VIDEO section
VIDEO inputs / outputs VIDEO (composite)
(luminance signal)
FM tuner section
Tuning frequency range
Total harmonic distortion (1 kHz)
MONO
Signal to noise ratio (1 kHz, 75 kHz DEV.)
MONO
Stereo separation (1 kHz) 38 dB Selectivity (±400 kHz) 50 dB
Frequency response
AM tuner section
Tuning frequency range
9 kHz step
Usable sensitivity
Signal to noise ratio (30% mod. 1 mV input) 50 dB
GENERAL
Power consumption KRF-V5030D190 W
KRF-V7030D/V6030D250 W
AC outlet SWITCHED (total 90 W max.)
Dimensions
H : 143 mm D : 400 mm

Weight (Net)(KRF-V7030D/V6030D) 7.4 kg (Net)(KRF-V5030D) 7.2 kg

Notes

- 1. KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.
- 2. The full performance may not be exhibited in an extremely cold location (under a water-freezing temperature).

Component and circuit are subject to modification to insure best operation under differing local conditions. This manual is based on Europe (E) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

KENWOOD CORPORATION

14-6, Dogenzaka 1-chome, Shibuya-ku, Tokyo, 150-8501 Japan

KENWOOD SERVICE CORPORATION

P.O BOX 22745, 2201 East Dominguez St., Long Beach, CA 90801-5745, U.S.A.

KENWOOD ELECTRONICS CANADA INC.

6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

KENWOOD ELECTRONICS LATIN AMERICA S.A.

P.O BOX 55-2791, Piso 6 plaza Chase, Cl. 47 y Aquilino de la Guardia Panama, Republic de Panama

KENWOOD ELECTRONICS BRASIL LTDA.

Av. Moema, 170-17°, Andar-Cobertura "B", Ed. Maximum Service Center, 04077-020 Moema, São Paulo-SP-Brasil

KENWOOD ELECTRONICS U.K. LIMITED

KENWOOD House, Dwight Road, Watford, Herts., WD1 8EB., United Kingdom

KENWOOD ELECTRONICS BELGUM N.V.

Meachelsesteenweg 418, B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

Rembrücker Str. 15, 63150 Heusenstamm, Germany

KENWOOD ELECTRONICS FRANCE S.A.

13 Boulevard Ney, 75018 Paris, France

KENWOOD ELECTRONICS ITALIA S.p.A.

Via G. Sirtori, 7/9 20129, Milano, Italy

KENWOOD IBÉRICA S.A.

Bolivia, 239-08020 Barcelona, Spain

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD.

(A.C.N. 001 499 074) 16 Giffnock Avenue, North Ryde, N.S.W. 2113, Australia

KENWOOD ELECTRONICS (HONG KONG) LTD.

Unit 3712-3724, Level 37, Tower 1, Metroplaza, 223 Hing Fong Road, Kwai Fong N.T., Hong Kong

KENWOOD ELECTRONICS GULF FZE

P.O.Box 61318, Jebel Ali, Dubai, U.A.E.

KENWOOD ELECTRONICS SINGAPORE PTE LTD.

No. 1 Genting Lane #02-02, KENWOOD Building, Singapore, 349544

KENWOOD ELECTRONICS (MALAYSIA) SDN BHD.

#4.01 Level 4, Wisma Academy Lot 4A, Jalàn 19/1 46300 Petaling Jaya Selangor Darul Ehsan Malaysia

KENWOOD ELECTRONICS (THAILAND) CO., LTD.

2019 New Pechburi Road, Bangkapi, Huaykwang, Bangkok, 10320 Thailand